

INSTRUCTION MANUAL FT-101ZD

YAESU MUSEN CO., LTD.

TOKYO JAPAN

TABLE CONTENTS

	(Page)
GENERAL DESCRIPTION	1
SPECIFICATIONS	2
TUBES AND SEMICONDUCTORS	3
CONTROLS AND SWITCHES	4
REAR APRON CONNECTIONS.....	7
ACCESSORIES	8
INSTALLATION	10
OPERATION	12
BLOCK DIAGRAM.....	21
CIRCUIT DESCRIPTION.....	22
MAINTENANCE AND ALIGNMENT.....	34
PARTS LIST	43

HIGH—PERFORMANCE HF TRANSCEIVER

YAESU FT-101ZD



GENERAL DESCRIPTION

The FT-101ZD is a precision engineered, high-performance HF transceiver of advanced design, providing all band (160 - 10 meters, plus WWV/JJY) operation on SSB and CW. This transceiver operates at an input power of 180 watts.

Advanced features include digital plus analog frequency display, continuously variable IF bandwidth (300 Hz - 2.4 kHz), a superb noise blanker with threshold adjustment, and an effective RF speech processor. The receiver boasts excellent dynamic range, despite its high sensitivity, for reliable operation in the presence of strong signals.

Built into every FT-101ZD are VOX, semi-break-in CW with sidetone, a 25 kHz crystal calibrator, selectable AGC, and a 10 dB/20 dB RF attenuator in the incoming signal path.

The FT-101ZD has been engineered for use. Controls and switches are laid out in an efficient and logical manner, so you won't have to fumble for a switch or knob when you need it quickly. And Yaesu designers have now made it possible for you to switch sidebands without recalibrating the display.

All circuits, except the transmitter driver and final amplifier stages, are solid state. Solid state devices provide extremely high reliability and high component density, along with low power drain. The FT-101ZD may be operated from a variety of AC voltages, from 100 to 234 volts. A DC-DC converter, providing operation from a 13.5 VDC power source, is an available option.

For the economy FT-101Z, the counter unit is an available option, providing digital display capability should you want to upgrade your transceiver at a later date. Optional equipment on both models FT-101ZD and FT-101Z are the cooling fan, DC-DC converter, 600 Hz CW filter, and microphone.

A diecast front panel, and the heavy-duty case, provide maximum protection for your transceiver. If the ratings of this unit are not exceeded, it will provide the owner with many years of satisfying operation. Please read this manual carefully before commencing operation, in order to derive maximum satisfaction from your new YAESU transceiver.

SPECIFICATIONS

Frequency coverage:

160 m	1.8 - 2.0 MHz
80 m	3.5 - 4.0 MHz
40 m	7.0 - 7.5 MHz
20 m	14.0 - 14.5 MHz
15 m	21.0 - 21.5 MHz
10 m	28.0 - 29.9 MHz
WWV/JJY	5.0 - 5.5 MHz

Power requirements:

AC	100/110/117/200/220/234 volts, 50/60 Hz
DC	13.5 volts \pm 10%

Power consumption:

AC	85 VA receive (73 VA HEATER OFF) 330 VA transmit
DC	5.5 amps receive (1.1 amps HEATER OFF) 21 amps transmit

Size:

345 (W) x 157 (H) x 326 (D) mm

Weight:

Approx. 15 kg.

TRANSMITTER

Emission type:

LSB, USB, CW

Power input:

180 watts DC

Carrier suppression:

Better than 40 dB

Unwanted sideband suppression:

Better than 40 dB (14 MHz, 1 kHz)

Spurious radiation:

Better than 40 dB down

Transmitter frequency response:

300 - 2700 Hz (-6 dB)

Third order distortion products:

Better than 31 dB down

Transmitter frequency stability:

Less than 300 Hz after 10 minute warmup;
less than 100 Hz after 30 minute warmup.

Antenna output impedance:

50 - 75 ohms, unbalanced

Microphone input impedance:

500 - 600 ohms (low impedance)

RECEIVER

Sensitivity:

0.25 μ V for S/N 10 dB

Image rejection:

Better than 60 dB (160 - 15 m)
Better than 50 dB (10 m)

IF rejection:

Better than 70 dB (160, 80, 20, 15, 10 m)
Better than 60 dB (40 m)

Selectivity:

SSB 2.4 kHz at 6 dB down, 4.0 kHz at 60 dB
down
CW (with optional CW filter) 600 Hz at 6 dB
down, 1.2 kHz at 60 dB down

Bandwidth control:

Continuous from 2.4 kHz to 300 Hz

Audio output impedance:

4 - 16 ohms

Audio output:

3 watts at 10% THD, 4 ohm load

Specifications subject to change without notice.

TUBES AND SEMICONDUCTORS

Vacuum tubes

12BY7A	1
6146B	2

Transistors

T20A6	2
2SA496Y	1
2SA564A	3
2SA639	1
2SA733	1
2SB616	1
2SC372Y	25
2SC373	2
2SC535A	1
2SC1000GR	2
2SC1383	1
2SC1583	2
2SC1815Y	4
2N4427	1
MPS3640	1
MPSA13	1

Field Effect Transistors

2SK19GR	10
2SK19BL	1
3SK40M	2
3SK51-03	7
J310	2

Integrated Circuits (IC)

μ PC78L05	1
μ PC78L12	1
μ PC14305	1
μ PC14308	1
μ PC2002H	1
MC3403P	1
MC10116	1
MC14024B	1
MSM561RS	6
MSM5564	1
SN76514N	1
SN74LS04N	1
SN74LS123N	1
SN74196N	1
SN74LS196N	6
TA7060P	1
TA7063P	1

Germanium Diodes

1N60	10
1S1007 (GB)	10

Silicon Diodes

1S1555	92
10D1	4
10D10	8
V06B	2

Zener Diodes

WZ061	1
WZ090	1

Varactor Diodes

1S2209	1
1S2236	1

Light Emitting Diodes

GD4-203SRD	9
------------	---

LED Display


HP-5082-7623	6
--------------	---

FT-101ZD SERIES MODEL CHART

○ = BUILT-IN FEATURE X = AVAILABLE OPTION

FEATURE	FT-101ZD	FT-101Z
ALL BAND CRYSTALS	○	○
COUNTER UNIT	○	X
DC-DC CONVERTER	X	X
CW FILTER	X	X
MICROPHONE	X	X
RF PROCESSOR	○	○
COOLING FAN	X	X

CONTROLS AND SWITCHES



(1) MODE

Selection of LSB, USB, CW-W (SSB filter), and CW-N (optional CW filter) is provided.

(2) WIDTH ON

When this button is pressed, the variable bandwidth function is activated.

(3) WIDTH

This control varies the IF bandwidth from 2.4 kHz down to 300 Hz. When the WIDTH switch is OFF, the bandwidth is fixed by the filter selected at the MODE switch.

(4) SELECT switches

When using the optional FV-901DM synthesized, scanning external VFO, these switches determine which component will control the transmit, receive, or transceive frequency.

EXT..... This switch, when pressed, shifts control of the transceive frequency to the external VFO.

TX EXT... This switch, when pressed, shifts control of the transmit frequency to the external VFO.

RX EXT... This switch, when pressed, shifts control of the receive frequency to the external VFO.

VFO..... This switch selects control of the transceive frequency on the FT-101ZD internal VFO.

CH1, CH2.. These switches select optional fixed channels, transceive only.

(5) PRESELECT

The preselector control peaks the RF and IF stages for the frequency in use.

(6) BAND

The bandswitch selects the frequency band in use: 160 - 10 meters, plus WWV/JJY 5 MHz.

(7) CLARIFIER

The clarifier control allows offset of ± 2.5 kHz from the frequency established by the main tuning dial.

(8) (9) CLARIFIER SELECT switches

Press the RX button for offset of the receive frequency.

Press the TX button for offset of the transmit frequency.

Press both buttons for offset of the transceive frequency.

(10) AF GAIN

The AF GAIN control varies the output level of the audio amplifier stages. Clockwise rotation increases the audio output level.

(11) RF GAIN

The RF GAIN control varies the gain of the RF and IF stages. Clockwise rotation increases the gain of these stages.

(12) LOADING

This control tunes the output circuit of the final amplifier pi network to match the feedpoint impedance of the load.

(13) PLATE

This control tunes the plate circuit of the final amplifier.

(14) MAIN TUNING KNOB

Rotation of this knob selects the operating frequency, in conjunction with the setting of the bandswitch. One revolution of the dial produces a frequency change of approximately 17 kHz.

(15) DIGITAL DISPLAY

The digital display reads out the operating frequency, with resolution to 100 Hz. The display unit is built into the FT-101ZD, and is an available option for the FT-101Z.

(16) ANALOG DIAL

The analog dial allows readout of the operating frequency to better than 1 kHz. The combination of the precision dial mechanism and drive unit provides zero backlash at slow tuning rates.

(17) DIM

This control allows dimming of the meter and dial lamps.

(18) METER

The meter displays final amplifier cathode current (IC), relative power output (PO), and ALC feedback voltage.

(19) NB

This control varies the threshold point for the noise blanker, and should be set to the minimum point that provides the desired blanking action.

(20) DELAY

This control sets the delay time for the VOX relay. For voice-actuated SSB, or semi-break-in CW, the operator may select the delay time most suitable for his or her operating habits.

(21) VOX GAIN

The threshold level for the VOX (voice operated relay) system can be varied using this control. In the PTT position, PTT (push to talk) control is provided, for relay control via the microphone PTT switch or footswitch.

(22) DRIVE

This control sets the carrier level for CW and tuning purposes. When the RF processor is ON, this control varies the RF output on SSB, as well.

(23) MIC GAIN

This control sets the output level of the microphone amplifier stage. Clockwise rotation increases the mic gain level.

(24) COMP LEVEL

This control varies the compression level for the built-in RF speech processor.

(25) FUNCTION switches

PROC This switch activates the RF speech processor.

ATT This switch allows the insertion of 10 or 20 dB attenuators in the incoming signal path.

AGC S/F/OFF . . This switch allows selection of the desired AGC decay time. In the OFF position, the AGC is switched off, and the S-meter will not function.

PO/IC/ALC . . . In the PO position, relative power output is displayed on the meter. In the IC position, final amplifier cathode current is displayed. In the ALC position, ALC voltage is displayed. Regardless of the setting of the meter switch, the meter functions as an S-meter on receive.

NB/MARK In the NB position, the noise blanker is activated. In the MARK position, the internal crystal calibrator is activated.

(26) POWER

This is the main ON/OFF switch for the transceiver.

(27) HEATER



With the HEATER switch on, heater voltage is applied to the driver and final amplifier tubes. This switch may be turned off during periods of RX, when energy conservation is critical.

(28) PHONES


This is a standard 1/4" phone jack for use with headphones.

(29) MIC


This is a 4 conductor jack for microphone and PTT input.




Mic plug





Headphone and external speaker plug



Key plug




ACC plug



Pin plug

REAR APRON



(1) RF OUT

RF output of 3 volts RMS is available at this jack for use with a transverter. Output is from the driver stage.

(2) GND

For best transceiver performance, as well as protection from electrical shock, a good ground connection should be made at this point, using a heavy, braided wire of the shortest length possible.

(3) ANT

Standard "UHF" connector for the antenna.

(4) RCV ANT

This jack is switched in parallel with the ANT jack on receive, for use with an external receiver.

(5) PO ADJ

This control adjusts the relative power output meter.

(6) ACC

Transceiver operating voltages and relay connections can be accessed through the accessory jack. Please insert the ACC plug at all times, to provide heater voltage for the driver and final amplifier tubes.

(7) TONE OUT

The CW sidetone may be fed to an external receiver through this jack.

(8) A TRIP IN

Anti-trip input from an external receiver may be made via this jack, to prevent the receiver audio output from tripping the FT-101ZD VOX.

(9) KEY

The CW key may be connected at this point. Key-up voltage is 7 volts, and key-down current is 1.5 mA. Be sure your electronic keyer's output switch will handle these levels.

(10) EXT VFO

Connection of an external VFO, such as the FV-901DM, can be made at this jack.

(11) FUSE

This is the fuse holder. For 100 - 117 volts, replace with only a 5 amp use. For 200 - 234 volts, use a 3 amp fuse. Replace fuses only with a fuse of the proper rating.

(12) IF OUT

Wideband IF output is available at this jack for use with a spectrum analyzer, etc.

(13) POWER

Connect the AC power cord at this point, being certain that your AC supply voltage matches the voltage specification for your transceiver. See the transformer primary connection chart. When using the optional DC-DC converter, the DC supply is connected at this point. **DO NOT CONNECT THE AC POWER CORD TO A DC POWER SOURCE. OUR WARRANTY DOES NOT COVER DAMAGE CAUSED BY SUCH IMPROPER POWER CONNECTIONS.**

(14) TONE

This control varies the CW sidetone output level.

(15) A TRIP

This control varies the level of the VOX anti-trip circuit.

(16) PTT

External control of the transceiver PTT (push to talk) system may be made at this jack, for use with a footswitch, etc.

(17) PATCH

Microphone or phone patch input may be made at this jack. Impedance is 500 ohms.

(18) EXT SP

This is a miniature phone jack for speaker output. When a plug is inserted into this jack, the transceiver internal speaker will be cut off. Impedance is 4 - 16 ohms.

(19) DC-DC CONVERTER (OPTION)

The optional DC-DC converter allows operation from a 13.5 volt DC power source.

(20) COOLING FAN (OPTION)

The optional cooling fan keeps the tubes at a safe operating temperature, when they are used in a hot environment. The 2 pin fan power jack supplies 100 volts to the fan.

ACCESSORIES

The following accessories are included with your new transceiver:

(1) AC POWER CORD 1

The power cord comes equipped with a 6-prong connector for connection to the AC supply.

(2) ACC PLUG 1

The accessory plug allows access to relay contacts and transceiver operating voltages. The ACC plug must be inserted in the accessory socket for proper operation of the transceiver, whether or not external connections are being made.



(3) PHONO PLUG 2

Use these plugs for interface with station equipment via the FT-101ZD rear panel.

(4) SPARE FUSES 5A (3A) 1 each

When replacing fuses, be absolutely certain to use a fuse of the proper rating. **OUR WARRANTY DOES NOT COVER DAMAGE CAUSED BY IMPROPER FUSE REPLACEMENT.** For 100 - 117 volt AC operation, use a 5 amp fuse. For 200 - 234 volt operation, use a 3 amp fuse.

INTERCONNECTIONS



INSTALLATION

The FT-101ZD is designed to be a single-unit station for fixed or portable operation from AC power. Power supply connections providing for operation from a variety of source voltages are available. Please read the following sections carefully, so as to ensure proper installation of your new transceiver.

PRELIMINARY INSPECTION


Upon opening the packing carton, immediately give the transceiver a thorough visual inspection. Check to see that all controls and switches are working freely, and inspect the cabinet for any signs of damage. If any damage has been sustained, immediately contact the shipping company, and document the damage completely. Save the packing carton and foam packing material for possible use at a later date.

BASE STATION INSTALLATION

The FT-101ZD is designed for use in many areas of the world, using supply voltages that may differ from your local supply voltage. For this reason, be absolutely certain that the voltage specification marked on the rear of the transceiver agrees with the local AC supply voltage. **THIS INSPECTION MUST BE MADE BEFORE CONNECTING THE AC POWER CORD TO THE REAR APRON OF THE TRANSCEIVER.**

CAUTION

PERMANENT DAMAGE WILL RESULT IF IMPROPER AC SUPPLY VOLTAGE IS APPLIED TO THE TRANSCEIVER. OUR WARRANTY DOES NOT COVER DAMAGE CAUSED BY APPLICATION OF IMPROPER SUPPLY VOLTAGE. DO NOT CONNECT THE AC POWER CORD TO A DC POWER SOURCE.



The transceiver should be connected to a good earth ground. The ground lead should be made of a heavy, braided wire, and should be connected to the GND terminal on the rear apron of the transceiver.

MOBILE INSTALLATION

(Note: The DC-DC converter described herein is optional equipment. See your Yaesu dealer.)

When the optional DC-DC converter is installed, the FT-101ZD will operate satisfactorily from a 13.5 volt DC power source capable of providing the required current. The DC power cord is included with the DC-DC converter kit.

For under-dash mobile mounting, a special mobile mounting bracket is an available option for your transceiver. The FT-101ZD should be located away from heater ducts, and a minimum of two inches of air space on all sides is recommended, to allow proper air flow around the cabinet. Never stack other units above or below the FT-101ZD, as the accumulated heat from both units could cause damage.

The transceiver requires an average of 14 amps on transmit, with 2 amps on voice peaks. The DC power cable comes equipped with a 20 amp fuse. Be certain to use only a 20 amp fuse when making replacement.

When making battery connections, be absolutely certain that the RED lead is connected to the POSITIVE battery terminal, and the BLACK lead is connected to the NEGATIVE battery terminal. Reversed connections could cause permanent damage to the transceiver. **OUR WARRANTY DOES NOT COVER DAMAGE CAUSED BY IMPROPER SUPPLY CONNECTIONS.**

It is recommended that the power connections be made directly to the battery, instead of to the ignition switch, etc. The battery provides considerable filtering action against ignition noise, and connection to the ignition switch can place the power line in a noisy circuit. Keep the power lead as short as possible, and keep the lead away from ignition cables.

Before connecting the DC power cable to the transceiver, check the battery voltage with the engine running (battery charging). If the voltage exceeds 15 volts DC, the vehicle voltage regulator should be adjusted, so as to limit the highest charging rate to less than 15 volts. As well, do not operate the transceiver if the DC supply voltage is less than 12 volts. The transceiver should always be turned off when the car is started, to prevent voltage transients from damaging the power supply components.

ANTENNA CONSIDERATIONS

The FT-101ZD is designed for use with an antenna system presenting a 50 - 75 ohm resistive load at the antenna jack. While the transmitter output circuitry is designed for uniform response within this impedance range, significant departures from the 50 - 75 ohm specification will result in seriously degraded transceiver performance, and may result in damage to the final amplifier tubes.

If an open-wire feedline is used, or if the input impedance of the antenna system presents a higher or lower impedance than specified, some sort of antenna tuner must be used to provide the proper impedance for the transceiver. See your Yaesu dealer for details of the FC-901 antenna coupler.

For mobile operation, most of the commercially-available antennas will provide satisfactory results, if care is taken to tune the antenna for minimum SWR. The outer conductor of the coaxial cable should be securely grounded to the automobile chassis at the antenna mount. See your Yaesu dealer for details on the RSL series of mobile antennas.

OPERATION

The tuning procedure for this transceiver is not complicated. However, care should be exercised when tuning so that peak performance of the equipment is secured. The following paragraphs describe the procedure for receiver and transmitter tuning.

INITIAL CHECK

Before connecting the transceiver to the power source, be certain that the voltage specification marked on the rear of the transceiver matches your local supply voltage, and also confirm that a fuse of the proper rating is being used.

FREQUENCY SELECTION

Frequency readout on the FT-101ZD is by digital as well as analog displays. The FT-101Z uses analog display only. The analog readout dial provides resolution to 1 kHz, while the FT-101ZD digital display provides resolution to 100 Hz. The digital display may be added to the FT-101Z as an option. See your Yaesu dealer for details.

RECEIVE OPERATION

- (1) Preset the controls and switches as follows:
POWER OFF
HEATER OFF
VFO Switch pushed
VOX GAIN . . PTT position
RF GAIN Fully clockwise
AF GAIN . . . Adjust later for comfortable level
BAND Desired band
MODE Desired mode
PRESELECT . Desired band segment
AGC OFF
ATT OFF
MARK/NB . . . OFF
- (2) Turn the power switch to ON. The meter will light up, and the operating frequency will be displayed on the dial window (FT-101ZD). Adjust the AF GAIN control for a comfortable listening level, and adjust the PRESELECT control for maximum receiver noise or signal level. The PRESELECT control may require repeaking as the transceiver is tuned across the band.

- (3) The RX CLARIFIER may be utilized if the received signal is drifting. Push the RX button, and rotate the CLARIFIER control for offset of up to 2.5 kHz. A red LED indicator will light up when the clarifier is in use.
- (4) When pulse-type noise is encountered, the NB (Noise Blanker) switch should be activated. Advance the noise blanker level control (located on the front panel) to the point which provides the desired blanking. Do not advance the level control beyond the point required to eliminate the noise pulses.
- (5) For varying the width of the IF passband, press the WIDTH button, and rotate the WIDTH control. In the IF, two 8-pole crystal filters are used. One filter is fixed, and presents a boundary for the bandwidth. The center frequency is then varied across the passband of the second filter, using a mixing scheme that provides no change of pitch in the received signal.

The result is continuously variable bandwidth, from 2.4 kHz down to approximately 300 Hz. When the WIDTH switch is turned OFF, the second IF filter is instantly aligned with the first filter, returning the receiver to a 2.4 kHz bandwidth.

- (6) For extremely strong signals, the ATT (attenuator) switch may be activated, providing 10 dB or 20 dB of attenuation on the incoming signal path, depending on the position of the ATT switch.

TRANSMITTER TUNING

The following tuning procedure must be performed prior to commencing operation on the desired mode. See the paragraphs relating to the specific mode after basic transmitter tune-up has been accomplished.

Be certain that a dummy load or matched antenna is connected to the antenna receptacle on the rear apron of the transceiver. It is possible to damage the final amplifier components of this equipment if this simple precaution is not followed prior to commencing transmission.

Do not exceed 10 seconds of key-down time while tuning.

As well, be certain that the ACC plug is inserted into the rear apron ACC jack. Without this plug, there will be no power applied to the tube heaters. Heater voltage is applied through pins 1 and 2 of the accessory socket.

- (1) Preset the controls and switches as follows:

MODE TUNE
DRIVE Fully counterclockwise
DELAY Fully counterclockwise
MIC GAIN..... Fully counterclockwise
COMP LEVEL ... Fully counterclockwise
HEATER ON
PROC OFF
PO/IC/ALC IC
PLATE Set to desired band segment
LOADING 0
PRESELECT Peaked on receive for maximum response
TX CLARIFIER .. OFF (button not pushed)

- (2) Turn the HEATER switch ON, and wait 1 minute for the tube heaters to warm up.
- (3) Set the VOX GAIN switch to the MOX position. Observe the reading on the IC meter: it should read 50 mA with no drive applied. If it is not, adjust the rear panel BIAS control for a resting current of 50 mA on the IC meter. Be certain that the DRIVE control is fully counterclockwise for this adjustment.
- (4) Set the VOX GAIN switch to MOX. Advance the DRIVE control for a reading of 150 mA.
- (5) Peak the PRESELECT control for a maximum meter reading. If the meter reading exceeds 150 mA, reduce the setting of the DRIVE control.
- (6) Rotate the PLATE control for a minimum reading ("dip") on the IC meter. Return the transceiver to the receive mode by rotating the VOX GAIN switch out of the MOX position.

FINAL TUNING

Final transmitter tuning uses the relative power output setting of the METER switch. At full rated output, using a 50 ohm load, the PO meter will indicate between 1/2 and 2/3 of full scale deflection. If the PO reading is too high (off scale) or too low (1/4 scale or less), and if the load impedance is very close to 50 ohms, the PO ADJ control on the rear apron may be varied to provide the proper deflection. Once the PO meter is calibrated, off-scale deflections are the result of reflected power (high SWR), and corrective action may be required in the antenna system.

Set the controls as follows for final tuning:

- (1) Set the METER switch to PO. Rotate the DRIVE control to the 9 o'clock position.
- (2) Rotate the VOX GAIN control to the MOX position, and rotate the PRESELECT control for a maximum meter reading.
- (3) Rotate the LOADING control for a maximum meter reading. Rotate the PLATE control for a maximum meter reading.
- (4) Again rotate the LOADING control and PLATE control, each time advancing the DRIVE control approximately 2 steps, until the DRIVE control is fully clockwise. The transmitter is now tuned for maximum power output. Do not exceed the maximum tuning time stipulated previously. Return the VOX GAIN switch to the VOX position (out of the MOX position), return the METER switch to IC, and return the DRIVE control to the fully counterclockwise position.

SSB OPERATION

After completing the above tuning procedure, set the MODE switch to USB or LSB as desired. Set the VOX GAIN control to PTT, and activate the transmitter by pushing the microphone PTT switch or the footswitch, if used. With the METER switch set to the ALC position, speak into the microphone in a normal voice. Advance the MIC GAIN control until the meter kicks up to the midscale of the green-colored portion of the meter scale.

Note: When the METER switch is set to IC, voice modulation peaks will indicate 150 - 200 mA. Actual peak current, though, is approximately 2 times the indicated value.

To set the sensitivity of the VOX (voice-operated T/R switching) system, advance the VOX GAIN control slowly while speaking into the microphone. Advance the VOX GAIN control to the point where the speech signal activates the transmitter.

Set the antitrip potentiometer on the rear apron to the minimum point which prevents the speaker output from tripping the VOX. Do not use more VOX gain nor antitrip than is necessary. Adjust the front panel DELAY control for the desired relay recovery time.

RF SPEECH PROCESSOR ADJUSTMENT

The FT-101ZD RF speech processor, when correctly adjusted, will improve the intelligibility threshold at the receiving end, by increasing the average SSB power output. RF clipping is applied to the IF signal, which is then filtered to remove harmonics and out of band intermodulation products. RF envelope clipping causes much less distortion than that caused by an equivalent amount of AF clipping, and the result is an output signal with more "punch".

Set the PROC switch to OFF, and set the MIC GAIN control as described previously (voice peaks falling within the green zone of the ALC meter scale). Now set the PROC switch to ON, and set the COMP LEVEL control to the 10 o'clock position. Advance the DRIVE control so that the desired power output is obtained, and be sure that the ALC meter indication is within the green zone.

With the RF speech processor activated, the ALC meter indication may not be quite as high as when the processor is off. This is entirely normal, because the average power output is higher with the processor, although the **peaks** are being clipped.

Setting the COMP LEVEL control up to the 12 o'clock position will provide up to 10 dB of compression. Advancing the control beyond the 10 o'clock point may, however, degrade the voice-to-noise ratio, so caution is recommended.

CW OPERATION

After completing the tuning procedure, insert the key line into the KEY jack on the rear panel.

The operator may select any power output desired by advancing the DRIVE control. Once the maximum power output level has been reached, the DRIVE control should not be advanced further.

The transmitter may be activated by the VOX circuit, or by the PTT or MOX systems. The TONE control on the rear apron of the transceiver sets the CW sidetone level.

The key-up voltage at the key jack is 7 volts, and the key-down current is 1.5 mA.

For receiving, two positions of selectivity are provided. When the optional CW filter is installed, the operator may select between the 600 Hz bandwidth of the CW filter and the 2.4 kHz bandwidth of the SSB filter. The WIDTH control may be used with either position of the MODE switch: CW-W or CW-N.

SELECT SWITCHES

The SELECT switches allow selection of internal or external VFO frequency control, as well as selection of up to 2 optional crystal-controlled channels.

When the crystal-controlled channels are installed, they may be selected by pressing CH1 or CH2, as desired. See the crystal information elsewhere for full information on crystal requirements.

When using the FV-901DM synthesized, scanning external VFO, available from your Yaesu dealer, your FT-101ZD will have available a 40-frequency memory bank, as well as a three-speed scanner. Because there is no calibrated display for the FV-901DM, the FV-901DM cannot be used with the analog FT-101Z.

For transceive frequency control on the external VFO, press EXT. For external VFO control of the transmit frequency, with receive frequency control on the FT-101ZD, press TX EXT. For receive frequency control on the external VFO, and transmit frequency control on the FT-101ZD, press RX EXT. For full transceive control on the FT-101ZD, press VFO.


DIAL CALIBRATION AND FREQUENCY DETERMINATION

The FT-101ZD mixing scheme accounts for the difference in carrier frequencies between USB and LSB. For this reason, no recalibration is required. Once the calibration is properly aligned (at the factory, or in shop), no further adjustment is required for accurate frequency derivation. The 25 kHz calibrator is included largely for alignment purposes, as it provides a useful reference signal for signal peaking, etc.

Frequency readout on the FT-101ZD digital display is straightforward. The full operating frequency is displayed, with resolution to 100 Hz.

The analog display on the FT-101Z and FT-101ZD transceivers provides easy determination of the operating frequency. The frequency displayed on the analog sub dial (and the main display window, for the FT-101Z) is added to the lower band edge frequency.

For example, if the analog dial indicates 074, as shown in the example, and the BAND switch is on 40 meters (lower band edge: 7000 kHz), the operating frequency will be 7074 kHz. By rotating the BAND switch, this position of the analog display will produce 14074 kHz for 20 meters, 21074 for 15 meters, etc. For 80 meters, the lower band edge is 3500 kHz, while for 160 meters the band edge is 1.5 MHz. Therefore, the dial should read 074 to produce 3574 kHz, but 374 for 1874 kHz. Be careful so as not to operate outside the amateur bands.



FIXED CHANNEL CRYSTAL INFORMATION

Two fixed channels may be used with your FT-101ZD, using optional crystals. Crystals are available from your Yaesu dealer. Crystals must meet the specifications shown in Table 2 , and must fall within the operating range 5500 - 5000 kHz. Frequency calculation is made from the formula

$$F_x = F_1 - F_0$$

where F_x is the crystal frequency
 F_1 is a constant derived from Table 1
 F_0 is the operating frequency.

For example, let us say it is desired to operate on 7199 kHz LSB. Referring to Table 1 , we see than for 40 meter LSB, F_1 is 12501.5 kHz. Subtracting F_0 (7199 kHz) from F_1 (12501.5 kHz) yields 5302.5 kHz, the crystal frequency (F_x).

For operation on 21420 kHz USB, compute the crystal frequency as follows:
 $F_x = 26498.5 - 21420 = 5078.5$ kHz.

Inspection of the values of F_1 in Table 2 will reveal that the 7199 kHz crystal for LSB will work on 14199 kHz, 21199 kHz, etc. Of course, LSB is not normally used on these bands. If the operator switches to USB, the operating frequency will be moved 3 kHz (in this case, to 14196 kHz, 21196 kHz, etc.). If the move is made from LSB to CW, the frequency will move 2.3 kHz down.

<div>MODE</div> <div>BAND</div>	U S B	L S B	C W
160m	6998.5	7001.5	6999.2
80m	8998.5	9001.5	8999.2
40m	12498.5	12501.5	12499.2
20m	19498.5	19501.5	19499.2
15m	26498.5	26501.5	26499.2
10m A	33498.5	33501.5	33499.2
10mB	33998.5	34001.5	33999.2
10mC	34498.5	34501.5	34499.2
10mD	34998.5	35001.5	34999.2

Table 1

Type	HC-25/U
Load Capacitance	30pF
Series Resistance	25 Ohms or less
Static Capacitance	7pF or less
Drive Level	5mW

Table 2

CW FILTER INSTALLATION (OPTION)

- (1) Remove the top cover of the transceiver case, as shown in Fig. 1.
- (2) Refer to Fig. 2, and locate the NB-FIX circuit board. Remove its mounting screws, because this board is obstructing the removal of the IF unit.
- (3) Remove the 12-pin, 13-pin, and 15-pin plugs from their sockets on the IF unit. Remove the IF unit mounting screws, and remove the IF unit from the transceiver case.




Figure 1




Figure 3

- (4) Install the optional CW filter as shown in the foil side view of the IF unit (Fig. 3). Make the fastening nuts snug, and solder the pins of the filter to the circuit board, and remove the 2 jumper wires shown in Figure 3.
- (5) Re-install the IF unit, being careful to connect the 12-pin, 13-pin, and 15-pin plugs in the correct sockets. Refer to Fig. 2 to be sure. Re-install the NB-FIX unit, and replace the top cover of the transceiver.
- (6) When the optional CW filter is installed, the CW-N position of the mode switch will activate this filter. In the CW-W position, the SSB 2.4 kHz filter will be in use. The WIDTH control is usable in all modes.




Figure 2




Figure 4

DC-DC CONVERTER INSTALLATION (OPTION)

The optional DC-DC converter is easy to install in a matter of minutes. Please follow the instructions carefully, in order to make the proper connections.

- (1) Install the DC-DC converter module as shown in the drawing. Use the four screws supplied with the kit. Do not force the plug into the socket, as the connection should be smooth, yet solid.
- (2) Check the DC cable fuse socket, located in the positive (red) lead, to be certain that a 20 amp fuse is installed.
- (3) When making connections to the battery, be absolutely certain that the proper polarity is observed. The RED lead should be connected to the POSITIVE (+) battery terminal, and the BLACK lead should be connected to the NEGATIVE (–) terminal. **OUR WARRANTY DOES NOT COVER DAMAGE CAUSED BY REVERSED POLARITY CONNECTIONS.**
- (4) Before connecting the DC power cable to the transceiver, check the automobile voltage regulator level with the engine running (battery charging). The maximum charging rate

should be 15 volts or less. If the voltage is higher than this level, please adjust the voltage regulator for a maximum of 15 volts. This precaution applies, as well, to bench power supplies, which should be adjusted in the same fashion. Also, the transceiver should not be operated from a supply voltage of less than 12 volts.


- (5) Connect the DC cable to the transceiver. Power connections are made automatically when the DC cable is connected to the POWER jack.

NOTES ON MOBILE INSTALLATION

Be certain that sufficient room is provided for free air circulation around the transceiver. If the transceiver must be placed on the car seat, set it on a board or other rigid object, in order to provide the necessary air circulation (and to avoid possible heat damage to the upholstery).

A special mobile mounting bracket is available from your YAESU dealer.

The DC supply should be capable of providing 20 amps on voice peaks, 14 amps continuous. The HEATER switch may be turned off during long periods of reception, for energy conservation.





COOLING FAN INSTALLATION (OPTION)

The FT-101ZD cooling fan may be used with other models of Yaesu equipment. Installation is easily accomplished in minutes.

Hold the fan up to the rear panel in its proper location. Determine the proper length of the two-wire power lead to the motor. Solder the leads to the 2-pin plug supplied with the fan. The 4-pin plug is not needed for FT-101ZD installation.

Install the fan onto the rear panel of the transceiver, as shown in the drawing. Insert the power lead from the fan into the fan socket on the rear panel.



Fan plug

COUNTER UNIT INSTALLATION ON FT-101Z

This section will deal with the installation of the COUNTER UNIT and digital display, which are optional equipment for the economy FT-101Z model.

PARTS NEEDED

Optical Filter with double-face tape	(1)
Counter Module	(1)
Guide Pins	(2)
Support Tower	(1)
Vinyl Tubes	(2)

- (1) Remove the top cover of the transceiver, according to the drawing on page 17.
- (2) Remove the screws marked "A" in Figure 1. These screws support the LED board.
- (3) Remove the screws marked "B" in Figure 1, as well as the tension spring, and remove the analog display panel.
- (4) Locate the analog display lamp. Cut the leads to this lamp, insert 1 lead each into the vinyl tube supplied with the counter kit, and position these leads out of the way of the VFO gears, etc.
- (5) Install the orange optical filter on the inside of the front panel of the transceiver, in the position formerly occupied by the analog display panel. Be sure that it is correctly centered. The filter is held in place by the double-face tape included with the filter.
- (6) Install the two guide pins into the holes previously occupied by the "A" screws. When doing this, install the LED board in its previous position. Install the support tower into the hole marked "C" in Figure 1.
- (7) Remove the 820 ohm (Gray-Red-Brown) resistor from the terminal strip marked "E" in Figures 1 and 2.
- (8) Install the COUNTER UNIT. The connection to the guide pins should not be forced. Use the screws previously installed at "A" for securing the counter module at points "C" (support) and "D" in Figure 1. Connect the COUNTER UNIT 9-pin plug into the 9-pin

socket on the transceiver at point "G" in the drawing. The coaxial cable from the COUNTER UNIT is connected to point "F" in Figure 1.

- (9) Close the transceiver. No alignment of the unit is necessary, unless some change in the preset carrier frequencies is required for a special application. In this case, refer to the section on the COUNTER UNIT in the "ALIGNMENT" chapter of this manual.





Figure 1



(Enlarged) Part E

Figure 2





Figure 3



CIRCUIT DESCRIPTION

The block diagram and following circuit description will provide you with a better understanding of the design of this transceiver. The circuit description is tailored to the full-feature FT-101ZD, and the reader should note that the counter unit and digital display are optional features for the FT-101Z.

The FT-101ZD consists of a premix-type single conversion system, using a 9 MHz IF for all modes of operation.


RECEIVER

The RF input signal from the antenna is fed through antenna relay RL_2 , lamp fuse FH_2 , attenuator switch S_{2004} (located on the LEVER SW unit, PB-1975), 9 MHz trap L_{2101} and C_{1207} (located on the TRIMMER A UNIT), and input transformer T_1 to pin 3 of the RF UNIT.

RF UNIT (PB-1960)

The incoming signal is amplified by the RF amplifier, Q_{101} (3SK51-03), a dual-gate MOSFET used in a grounded source configuration. This transistor has superior immunity from intermodulation distortion. The amplified signal is then fed through a source follower, Q_{102} (J310), to the balanced mixer consisting of Q_{103} and Q_{104} (2SK19GR), where the input signal is heterodyned with the local oscillator signal. The local signal is delivered from buffer amplifier Q_{107} (2N4427), and the resulting IF signal of 8.9875 MHz is fed through T_{102} to J_{101} .

The input and output of the RF amplifier are permeability-tuned circuits, resulting in high sensitivity and excellent rejection of unwanted out-of-band signals.



IF UNIT (PB-1963)

The IF signal at pin 9 of J₄₀₃ is amplified by Q₄₀₈ (J310) and passed through a monolithic filter, XF₄₀₄, which has a ± 10 kHz bandwidth. The monolithic filter provides early protection from IMD, while providing a wide-bandwidth point for noise blanking. The IF signal is then fed to noise blanker gate D₄₀₄ (1S1007), which functions as an ON/OFF switch controlled by noise blanker driver Q₄₁₁ (MPSA13).

The IF signal is then passed through the SSB filter XF₄₀₁ (or optional CW filter XF₄₀₂). Selection of the filter to be used is made by diodes D₄₀₅ - D₄₀₈ (1S1007), depending on the mode of operation.

The IF signal is then fed to the IF first mixer, Q₄₁₂ (3SK51-03), where the incoming signal is heterodyned with a 19.7475 MHz $\pm \Delta f$ local signal delivered from crystal oscillator Q₄₂₁ (2SC535A) and buffer amplifier Q₄₂₃ (2SC372Y), resulting in a signal of 10.76 MHz $\pm \Delta f$.



The new 10.76 MHz $\pm \Delta f$ signal is fed through filter XF₄₀₅ to the IF second mixer, Q₄₁₃/Q₄₁₄ (2SK19GR), where the filtered signal is heterodyned with the 19.7475 MHz $\pm \Delta f$ signal delivered from Q₄₂₂ (2SC372Y), resulting in an 8.9875 MHz IF signal, the same as the original IF.

This process varies the IF signal across the passband of the second IF filter. The combination of the two filters, XF₄₀₁ and XF₄₀₅, provides continuously variable width of the IF passband. The frequency of crystal oscillator Q₄₂₁ is varied by varactor diode D₄₁₈ (1S2209).


The output from the IF second mixer is fed to a two-stage IF amplifier, consisting of Q₄₁₅ and Q₄₁₆ (3SK51-03), and delivered through diode switch D₄₀₁ (1S1555) to the AF UNIT.

A portion of the output from Q₄₁₆ is rectified by D₄₁₆ and D₄₁₇ (1N60) to produce AGC voltage. Q₄₁₇ (2SC372Y) provides the necessary buffering between the IF and AGC circuits. The AGC voltage is amplified by Q₄₁₈ (2SC372Y), and applied to gate 2 of the RF and IF amplifiers, to control the gain of these stages. The AGC voltage is also amplified by Q₄₁₉ (2SK19GR) for S-meter indication.

For use with the FV-901DM scanning VFO, or other optional equipment, the AGC voltage is fed through buffer Q₄₂₅ (2SK19GR) and fed to the AGC OUT terminal on the EXT VFO jack, located on the rear panel.



Width Control Action



PB-1963 IF UNIT (NO. 4...)

NB-FIX UNIT (PB-1961)

A portion of the 8.9 MHz IF signal is fed through buffer Q_{410} (2SC372Y) and amplified by Q_{206} and Q_{205} (2SC1583).

When a carrier of noise-free modulated signal is received, the IF signal is rectified by D_{201} and D_{202} (1N60), producing a DC voltage. This DC voltage is amplified by Q_{202} (2SC372Y), which charges C_{214} , for AGC purposes. The AGC voltage is used to control the gain of Q_{206} and Q_{205} .

When impulse-type noise is received, D_{203} and D_{204} (1N60) rectify the IF signal, producing a DC voltage which controls the NB switch Q_{411} (2SC372Y).

Noise pulses have a very short duration, but high amplitude. Because of the very slow time constant of the C_{214}/R_{212} discharge path, AGC voltage is not induced by these short-duration pulses. Therefore, Q_{206} and Q_{205} operate at full gain, providing maximum voltage to the base of Q_{411} . When a pulse is received, Q_{411} biases D_{414} to block the signal path momentarily. When a desired signal and a noise pulse are received simultaneously, the blanking action is not impaired, because the relative amplitude difference between the desired signal and the noise pulse is still high. The front panel noise blanker level control varies the DC voltage applied to the base of Q_{411} .

AF UNIT (PB-1964)

The IF signal from pin 2 is fed through T_{501} to the ring demodulator, consisting of $D_{502} - D_{505}$ (1S1007), where the IF signal is demodulated into audio, using the carrier signal delivered from Q_{503} (2SC1815Y). The carrier signal is generated by oscillator Q_{514} (2SK19GR), and it oscillates at one of the following frequencies:


USB, CW·RX	8989 KHz
LSB	8986 KHz
CW·TX	8988.3 KHz


The audio signal is then amplified by audio amplifiers Q_{507} , Q_{508} (2SC1000GR), and Q_{509} (μ PC2002), delivering 3 watts of audio output to the speaker.

The audio spectrum is shaped by an active low-pass filter of $f_0 = 2.7$ kHz, -12 dB/octave.

MARKER GENERATOR

A 25 kHz marker signal is provided, for alignment and testing purposes. Marker generator Q_{509} (2SC1815Y) generates a basic 3200 kHz signal, which is divided into 25 kHz multiples by Q_{506} (MC14024B), a binary counter.





TRANSMIT CIRCUIT

SSB MODE

The output from microphone jack J_2 is fed through the MIC GAIN control VR_{3a} to pin 8 of the AF UNIT.

AF UNIT (PB-1964)

The speech signal from pin 8 is amplified by microphone amplifier Q_{502} (TA7063P) and fed through relay RL_{501} to the ring modulator, $D_{502} - D_{505}$, where the speech signal modulates the carrier signal delivered from Q_{513} . The resulting double sideband signal is fed to the IF UNIT.

IF UNIT (PB-1963)

The 8.9875 MHz double sideband signal is amplified by Q_{401} (3SK51-03) and passed through sideband filter XF_{401} by diode switches D_{403} , D_{409} (1S1555), D_{405} , and D_{407} (1S1007). Here the signal is converted to a single sideband signal by removal of the unwanted sideband.

The signal is then fed to buffer amplifier Q_{402} (2SK19GR). When the RF speech processor is OFF, diode switches D_{411} and D_{412} (1S1555) feed the IF signal to IF amplifier Q_{405} (3SK51-03). When the RF speech processor is ON, the SSB signal is amplified by buffer amplifier Q_{402} (2SK19GR) and further amplified by limiter Q_{403} (TA7060P), where signals that exceed the preset clipping level are sliced out.

This highly clipped SSB signal is amplified by buffer amplifier Q_{404} (2SC372Y) and passed through a selective filter, XF_{403} , which removes RF harmonics that result from signal clipping. The signal is then fed to IF amplifier Q_{405} , and subsequently delivered to the RF UNIT. The front panel COMP LEVEL control, VR_4 , controls the voltage at gate 2 of Q_{401} , thus setting the processor level.

The return of the grid circuit of the final amplifier tubes is fed to Q_{406} (2SK19BL), which produces ALC voltage. This voltage is fed to gate 1 of Q_{405} ,

controlling the gain of this stage. When the RF processor is off, ALC voltage is also fed to gate 1 of Q_{401} . Q_{407} (2SA564) amplifies the ALC voltage for indication on the front panel meter.

RF UNIT (PB-1960)

The IF signal is fed through T_{104} to the transmit mixer, consisting of parallel-connected Q_{105} and Q_{106} (3SK40M), where the IF signal at gate 1 is mixed with the local signal fed to gate 2, producing the RF output signal. The RF signal is then fed through diode switch D_{104} (1S1007) to the DRIVE UNIT.

DRIVE UNIT (PB-1714), PA UNIT (PB-1715)

The RF signal is amplified by driver V_{1601} (12BY7A), and delivered to PA UNIT final amplifier tubes V_{1701} and V_{1702} (6146B). The output from the final tubes is fed to the antenna jack.

A portion of the RF signal is coupled through C_{14} to the cathode of the 12BY7A driver, for the purpose of improving the linearity of the final amplifier. This technique is known as RF negative feedback.

CW MODE

For CW, the 8.9883 MHz carrier is generated by oscillator Q_{514} at the frequency set by X_{504} . The carrier signal is fed through buffer Q_{513} and fed to the ring modulator. The same carrier frequency is used in the tune mode.

DC voltage is applied through diode switch D_{517} (1S1555) and relay RL_{501} , unbalancing the ring modulator for CW operation. The carrier signal is then fed to the IF UNIT. The signal path is identical to that on SSB, up to the DRIVE UNIT.

DRIVE UNIT (PB-1714), PA UNIT (PB-1715)

Keying of the transmitter is accomplished by changing the bias voltage to the driver and final tubes. During "key up," the tubes are cut off by application of -35 volts to V_{1601} and -110 volts to V_{1701} and V_{1702} . These cutoff voltages are

reduced to -0.1 volt and -60 volts, respectively, during "key down" conditions.

The key is connected to the KEY 2 terminal on the RECT B board, PB-1968. When the key is closed, the base of Q_{1001} (2SA733) is grounded, causing Q_{1002} (2SC372Y) to conduct. The base of Q_{1003} (2SA639) is thus set to 0 when the transistor conducts. Under these circumstances, the bias voltage applied to V_{1601} , V_{1701} , and V_{1702} places these tubes in the normal operating condition.

VOX circuit

A portion of the microphone input signal is amplified by three stages of Q_{503} (MC3403P), which drive the VOX control gate, Q_{504} (SN74LS123N). The output from pin 13 of Q_{504} is fed to the base of Q_{512} (2SC1383), switching the VOX relay on and off according to the presence or absence of a speech signal.

A portion of the speaker output is detected by D_{510} and D_{511} (1N60), providing a bucking voltage which is fed to Q_{503} , preventing the speaker output from tripping the VOX.

The VOX delay may be set by adjusting VR_{2b} for the desired delay time.

CW SIDETONE

CW sidetone oscillator Q_{511} (2SC373) oscillates at a frequency of approximately 800 Hz. The output from Q_{511} is amplified by the final audio

amplifier, Q_{501} , for delivery to the speaker. The output from the sidetone oscillator is also fed to VOX amplifier Q_{503} , providing semi-break-in operation for CW.

COMMON CIRCUITS

VFO UNIT (PB-1440B-3420)


A modified Colpitts-type oscillator is used to generate a 5.0 - 5.5 MHz VFO signal, thus producing a 500 kHz tuning range. The oscillator signal generated by Q_{801} (2SC372Y) is varied by VC_{801} , which is geared to a precision-built dial tuning mechanism. VC_{801} consists of two sections; the sub-blades compensate for the capacitance variation of the main blades, which may result from extreme temperature change.

Varactor diode D_{801} (1S2209) may be varied by tuning L_{806} , providing ± 2.5 kHz offset from the dial frequency (clarifier).

The VFO signal is amplified by buffer amplifiers Q_{802} (2SK19GR) and Q_{803} (2SC372Y), and passed to the PREMIX UNIT.

NB & FIX UNIT (PB-1961)

Two crystal-controlled channels are provided for operation with this transceiver. The oscillator signal is generated by Q_{203} (2SC372Y) and amplified by Q_{204} (2SC372Y), and delivered to the PREMIX UNIT. Crystals X_{201} and X_{202} oscillate in the 5.0 - 5.5 MHz range.



PREMIX LOCAL UNIT (PB-1711)



Crystal oscillators $Q_{601} - Q_{610}$ (2SC372Y) generate the premix local signal at the frequencies shown in Table 3. Diode switches $D_{601} - D_{610}$ (1S1555) select the proper local signal for the band in use. The local signal is then delivered to the PREMIX UNIT.

		XCO Frequency	PREMIX OUT Frequency
160m	X_{601}	15.9875MHz	10.4875~10.9875MHz
80m	X_{602}	17.9875MHz	12.4875~12.9875MHz
40m	X_{603}	21.4875MHz	15.9875~16.4875MHz
20m	X_{604}	28.4875MHz	22.9875~23.4875MHz
15m	X_{605}	35.4875MHz	29.9875~30.4875MHz
10mA	X_{606}	42.4875MHz	36.9875~37.4875MHz
10mB	X_{607}	42.9875MHz	37.4875~37.9875MHz
10mC	X_{608}	43.4875MHz	37.9875~38.4875MHz
10mD	X_{609}	43.9875MHz	38.4875~38.9875MHz
JJY/ WWV	X_{610}	19.4875MHz	13.9875~14.4875MHz

Table 3

PREMIX UNIT (PB-1962)

The premix signal is produced at Q_{303} (SN76514N), a double-balanced mixer, where the premix local signal from $Q_{601} - Q_{610}$ is mixed with the VFO or crystal controlled 5 MHz signal. The premix output frequencies are shown in Table 3. The premix signal is passed through bandpass filter $T_{301} - T_{304}$, and amplified by Q_{301} (2SK19GR) and Q_{302} (2SC373). The amplified signal is then fed to the RF UNIT, where the signal is further amplified by Q_{107} for delivery to the transmitter and receiver mixers.



COUNTER UNIT (PB-1978, PB-1979, PB-1980)

The premix local signal from the PREMIX LOCAL circuit is fed to amplifier Q₂₃₀₁ (3SK51-03), located on PB-1980. The amplified signal is then fed to waveshaper Q₂₃₀₂ (MC10116). Q₂₃₀₃ (MPS3640) acts as an interface between Q₂₃₀₂ and the TTL circuitry. The signal is then fed to the counter gate, Q₂₃₀₄ (SN74S00N).

The clock pulses are generated by Q₂₃₀₅ (MSM5564), which produces a 655.36 MHz signal. The signal is divided by a factor of 2¹⁷, producing a 5 Hz signal which is fed to the counter gate.

The pulses which pass through the gate are fed to decade counter Q₂₃₀₉ (SN74196N), which counts 10 Hz digits. In turn, Q₂₃₀₂ - Q₂₃₀₇ (SN74LS196N) count 100 Hz, 1 kHz, 10 kHz, 100 kHz, 1 MHz, and 10 MHz digits. The BCD output signal from Q₂₃₀₂ - Q₂₃₀₇ is fed through drivers Q₂₂₀₈ - Q₁₂₁₃ (MSM561) to the display digits, DS₂₁₀₁ - DS₂₁₀₆ (HP 5082-7623).

The system of presetting the counter can best be explained by example. For a frequency of 3.500 MHz LSB, the premix local frequency is 12.486 MHz. The LSB preset code is 91.014.0. 12.486 + 91.0140.0 = 103.500. The “1” digit on the left-hand side is dropped (overflow), and the “0” preceeding the “3” causes a blanking signal to be sent to the 10 MHz digit. The result is a frequency of 3.500 MHz, and this number is displayed.

For USB, the preset number is 91.011.0. For a frequency of 14.000 MHz USB, the manipulation is as follows: 91.011 + 22.989 (Premix freq.) = 114.000. The first digit is the overflow digit, and the remaining digits are displayed. Note that the second digit from the left is not zero, so no blanking signal is sent to the 10 MHz digit.

For a CW frequency of 21.000 MHz, the premix frequency is 29.9883, and the preset frequency is 91.011.7. The manipulation is: 91.011.7 + 29.9883 = 121.0000. The first digit is dropped, and the remaining digits are displayed.

The preset frequencies are programmed by Q₂₃₀₇ and Q₂₃₀₈ (μPA54H) and diode matrix D₂₃₀₆ - D₂₃₁₂ (1S1555). Please refer to Table 5 for definition of the premix frequencies for the various bands.


The 5 volt supply is regulated by Q₂₃₁₀ (μPC 14305) for the TTL circuitry. The DIM control controls the emitter/collector voltage at Q₂₂₀₁ (2SA496Y), to control the brightness of the digital display and lamps.

	10MHz	1MHz	100kHz	10kHz	1kHz	100Hz
	(Q ₂₂₀₇)	(Q ₂₂₀₆)	(Q ₂₂₀₅)	(Q ₂₂₀₄)	(Q ₂₂₀₃)	(Q ₂₂₀₂)
LSB	9	1	0	1	4	0
USB	9	1	0	1	1	0
CW	9	1	0	1	1	7

Preset Number
Table 4

	Nominal Premix Local Frequency	L S B	U S B	C W
160m	10.4875–10.9875(MHz)	10.486–10.986(MHz)	10.489–10.989(MHz)	10.4883–10.9883(MHz)
80m	12.4875–12.9875	12.486–12.986	12.489–12.989	12.4883–12.9883
40m	15.9875–16.4875	15.986–16.486	15.989–16.489	15.9883–16.4883
20m	22.9875–23.4875	22.986–23.486	22.989–23.489	22.9883–23.4883
15m	29.9875–30.4875	29.986–30.486	29.989–30.489	29.9883–30.4883
10mA	36.9875–37.4875	36.986–37.486	36.989–37.489	36.9883–37.4883
10mB	37.4875–37.9875	37.486–37.986	37.489–37.989	37.4883–37.9883
10mC	37.9875–38.4875	37.986–38.486	37.989–38.489	37.9883–38.4883
10mD	38.4875–38.9875	38.486–38.986	38.489–38.989	38.4883–38.9883

Table 5



POWER SUPPLY

The power supply is designed to operate from 100/110/117/200/220/234 volts AC. A DC-DC converter is an available option, providing operation from 13.5 volts DC. Insertion of the appropriate power plug into the rear panel receptacle makes the necessary connections for AC or DC operation.


When the transceiver is operated from a DC 13.5 volt power source, using the optional DC-DC converter, transistors Q₃₂₀₁ and Q₃₂₀₂ (T20A6) function as a low frequency oscillator, providing AC voltage at approximately 80 Hz to the power transformer. All of the tube heaters receive their power through the HEATER switch on the front panel. When the HEATER switch is OFF, voltage is still supplied to the receiver section, thus allowing continuous reception with reduced power consumption. The heaters of the two 6146B are connected in series to operate at 12 volts DC.


The 14 volt AC power delivered from the secondary winding of the power transformer is rectified by D₉₀₅ and D₉₀₆ (V06B). Voltage regulators Q₁ (2SB616), Q₉₀₁ (78L12), and Q₉₀₃ (2SA495) stabilize the DC supply at 12 volts. The supply voltage is further stabilized at 8 volts by Q₃ (μPC14308) for delivery to the counter, AF, and other units. The 6 volt supply for the VFO is provided through zener diode D₉₀₈ (WZ061), while the 5 volt supply for the TTL integrated circuits is provided by Q₅₀₅ (78L05).

The power amplifier plate voltage of +800 volts is supplied from the bridge-controlled doubler, located on the RECT. A UNIT, and consisting of D₉₀₁ - D₉₀₄ (10D10).


AC 190 volts is rectified by D₁₀₀₂ (10D10), producing 210 volts for the screen grid supply of the power amplifier tubes. The screen grid voltage for the driver tube is obtained by rectifying 250 volts AC at D₁₀₀₁ (10D10), producing 300 volts. This voltage is dropped to 180 volts by a resistor for delivery to the driver tube screen grid.

The 120 volt AC power from the transformer secondary winding is rectified by D₁₀₀₃ (10D10) in order to obtain -140 volts for the driver and final amplifier tube grid bias.





TOP VIEW



BOTTOM VIEW

MAINTENANCE AND ALIGNMENT

WARNING

DANGEROUS VOLTAGES ARE PRESENT WITHIN THIS TRANSCEIVER. USE EXTREME CAUTION WHEN WORKING ON THE TRANSCEIVER WITH THE COVERS REMOVED. DISCHARGE ALL CAPACITORS BY SHORTING THEM TO GROUND WITH AN INSULATED SCREWDRIVER AFTER POWER HAS BEEN REMOVED. OBSERVE NORMAL SAFETY PRECAUTIONS AT ALL TIMES.

CAUTION

Never operate this transceiver in the transmit mode without a matched antenna or dummy load connected to the antenna receptacle on the rear panel. It is possible to damage the final amplifier tubes and the pi network components if the transmitter is operated without the proper load termination.

GENERAL

This transceiver has been carefully aligned and tested at the factory. With normal use, it should not require other than the usual attention given to electronic equipment. Service or realignment of a major component may require substantial adjustment; under no circumstances, though, should realignment be attempted unless the operation of the transceiver is fully understood, the malfunction has been carefully analyzed, and the fault has definitely been traced to misalignment. Sudden difficulties are almost always caused by component failure rather than misalignment.

Service work should only be performed by experienced personnel, using the proper test equipment.

EQUIPMENT REQUIRED

- (1) RF Signal Generator: Hewlett-Packard Model 606A or equivalent, with one volt output at 50 ohms, and frequency coverage to 30 MHz.
- (2) Vacuum Tube Voltmeter (VTVM): Hewlett-Packard Model 410B or equivalent, with an RF probe good to 40 MHz.
- (3) Dummy Load: Yaesu Model YP-150 or equivalent, with 50 ohm non-reactive load impedance, rated to 150 watts average power.
- (4) AF Signal Generator: Hewlett-Packard Model 200AB or equivalent.
- (5) A general coverage receiver covering 3 to 30 MHz, with a 100 kHz crystal calibrator.
- (6) A frequency counter, Yaesu Model YC-500 or equivalent, with resolution to 0.01 kHz and frequency coverage to 30 MHz.
- (7) An oscilloscope, Hewlett-Packard Model 1740A or equivalent.

AF UNIT ALIGNMENT

VOX Circuit

A. Antitrip level setting

1. Tune in a signal on the FT-101ZD receiver, and adjust the AF GAIN control for a normal listening level. Position the microphone near the speaker, with the MODE switch in the SSB mode. Increase the VOX GAIN control on the front panel until the speaker output causes the VOX relay to switch the transceiver to transmit. Set the ANTITRIP control VR₉, located on the rear apron, to the point that will just prevent the speaker output from tripping the VOX relay.
2. Now place the microphone in the normal operating position, and speak into the microphone to see if your voice will activate the VOX relay. If not, VR₉ may be advanced too far.

B. VOX relay delay setting

1. Adjust the DELAY control VR_{2b}, located on the front panel, for the desired delay time. This may require a different setting for phone and CW operation, owing to differing operating techniques. For CW or phone operation using a footswitch, the VOX GAIN control may be rotated fully counter-clockwise to the PTT position.

CW Sidetone

1. The CW sidetone level may be adjusted by means of VR₁₀, located on the rear apron.


Marker Frequency setting

1. Preset the controls as follows:
BAND JJY/WWV
DIAL 5000.0 kHz
PRESELECT . Peaked for maximum response
MODE TUNE
2. Place the NB/MARK switch in the MARK position. Tune in the WWV or JJY signal, and adjust TC₅₀₁ for an exact zero beat with the carrier of the incoming signal.

Carrier Frequency Adjustment

A. SSB Carrier Point

1. Tune up the transmitter on 20 meters, LSB mode, into a dummy load. Apply a 1 kHz audio signal to the microphone input, and adjust the audio generator output until the transmitter power output is 60 watts, as indicated on the dummy load wattmeter.
2. Shift the audio generator output frequency to 300 Hz, without changing the output level. Adjust TC₅₀₃ for a power output reading of 15 watts on the wattmeter.
3. Shift the MODE switch to USB. Adjust TC₅₀₄ for an identical 15 watt reading on the wattmeter.



AF UNIT(PB-1964)

4. Recheck the LSB adjustment, as well as the carrier balance adjustment, after performing the carrier point alignment. The background noise, when switching between USB and LSB, should not change.

B. Carrier Balance


1. Tune up the transceiver on 20 meters, USB mode, into a dummy load. Set the main tuning dial to 14.250 MHz. Connect the RF probe of the VTVM to the antenna jack. Disconnect all microphones, etc., from the microphone jack.
2. Activate the transmitter by placing the VOX GAIN control into the MOX position. Adjust VR₅₀₁ and TC₅₀₂ for a minimum VTVM reading.
3. If a VTVM is unavailable, use an external

monitor receiver, tuned to the transmitter frequency, and adjust VR₅₀₁ and TC₅₀₂ for a minimum S-meter reading on the external receiver.

4. This adjustment should be repeated several times on LSB and USB, in order to ensure complete carrier nulling.

C. CW Carrier Point

1. Connect a frequency counter to TP₄₀₂, located on the IF UNIT. Place the MODE switch in the TUNE position.
2. Adjust TC₅₀₅ for a frequency counter reading of exactly 8988.3 kHz.
3. When using the optional CW filter, a substantial loss on transmit, when in the CW-N position, may indicate the need for adjustment as indicated in steps 1 and 2.



IF UNIT ALIGNMENT

S-Meter Sensitivity Adjustment


1. Set the BAND switch to 20 meters, the main dial to 14.250 MHz, and set the RF GAIN fully clockwise.
2. Set the signal generator to 14.250 MHz, and set its output to 6 dB. Tune the signal generator signal on the receiver, and peak the preselector for maximum signal strength. The S-meter should just begin to move with the 6 dB input.
3. Adjust VR₄₀₃ for a reading of 0 on the S-meter.
4. Set the generator output to 100 dB, and adjust VR₄₀₅ for a reading of S9 + 60 dB on the S-meter. Confirm that the preselector is peaked.
5. Return the signal generator output to 6 dB, and recheck the adjustment of VR₄₀₃.

Variable IF Bandwidth Alignment

1. Set the controls as follows:
BAND 20 m
DIAL 14.200 MHz
RF GAIN Fully clockwise
WIDTH switch .. OFF
MODE USB
Peak the preselector for maximum response against the marker signal or background noise.
2. Connect the frequency counter to TP₄₁₁. Adjust VR₁₅₀₁ for a reading of exactly 19.7475 MHz.
3. Place the WIDTH switch ON. Make sure that the WIDTH control is exactly in the 12 o'clock position. Adjust VR₄₀₄ for a reading of exactly 19.7475 MHz on the frequency counter.
4. Switch between USB and LSB, and observe the background noise. If there is any difference, adjust VR₁₅₀₁ until the background noise is the same.

ALC Meter Alignment


1. On any band, set the MODE switch to USB. Set the meter switch to ALC.
2. With no speech input, activate the transmitter. Adjust VR₄₀₁ for a 0 reading on the ALC meter scale.



RECTIFIER B UNIT

Bias Adjustment

1. Set the MODE switch to USB or LSB, and set the MIC GAIN control fully counterclockwise.
2. Place the METER switch in the IC position, and set the VOX GAIN control to VOX. Adjust the rear apron BIAS control, VR₁₀₀₁, for a reading of 50 mA. For 10 watt models, the correct meter reading is 25 mA.



RECT. B UNIT (PB-1968)

VFO UNIT


The VFO UNIT is very critical in its adjustment. As well, this is not an area which should ever require alignment. Questions regarding drift, etc., usually can be traced to other areas of the transceiver (instability in the supply voltage, etc.). For this reason, all cases regarding VFO repair should be referred to an experienced service technician.

The following components are of interest from a service standpoint:

TC₈₀₁ is the band set trimmer.

TC₈₀₂ is the VFO level set trimmer.

To confirm proper VFO injection, connect the VTVM to the VFO output. Adjust TC₈₀₂ for a reading of 100 mV.



BAND	CRYSTAL	FREQUENCY	TRANSFORMER
160m	X 601	15.9875MHz	T601
80m	X 602	17.9875	T602
40m	X 603	21.4875	T603
20m	X 604	28.4875	T604
15m	X 605	35.4875	T605
10mA	X 606	42.4875	T606
10mB	X 607	42.9875	T607
10mC	X 608	43.4875	T608
10mD	X 609	43.9875	T609
JJY/WWV	X 610	19.4875	T610

Table 6

NB-FIX UNIT

Fixed Channel Frequency Alignment

When the optional fixed channel crystals are being used, they may be placed exactly on the correct frequency by adjusting TC₂₀₁ (for channel 1) and TC₂₀₂ (for channel 2). Confirmation of the correct frequency may be made with an external receiver or by loosely coupling a probe from the frequency counter to the transmitter output. A 1-turn loop is usually sufficient to provide indication on the counter.

PREMIX LOCAL UNIT

Premix Local Alignment

1. Connect the RF probe of the VTVM to pin 1 of MJ₃.
2. Refer to Table 6, and adjust the appropriate transformer for a level of 300 mV for each band and crystal, as shown in the table.


PREMIX UNIT

For this alignment, a wideband (not peak) sweep generator, as well as an oscilloscope, should be used.


1. Press the EXT select switch. Apply 5.0 - 5.5 MHz sweep output to the VFO output terminal at the rear apron external VFO jack. Connect a high-impedance probe of an oscilloscope to J₃₀₁.
2. Adjust the transformers shown in Table 7 for a flat response across the entire passband. If you have never adjusted a bandpass filter previously, this may take some practice. Perform the adjustments on each band, according to the chart.

BAND	TRANSFORMER	PASSBAND
160m	T ₃₀₁ , T ₃₀₂	10.4—11.0(MHz)
80m	T ₃₀₃ , T ₃₀₄	12.4—13.0
40m	T ₃₀₅ , T ₃₀₆	15.9—16.5
20m	T ₃₀₇ , T ₃₀₈	22.9—23.5
15m	T ₃₀₉ , T ₃₁₀	29.9—30.5
10mA	T ₃₁₁ , T ₃₁₂	36.9—39.0
JJY/WWV	T ₃₁₃ , T ₃₁₄	13.9—14.5


Table 7



NB-FIX UNIT(PB-1961)




PREMIX LOCAL(XTAL)UNIT(PB-1965)



PREMIX UNIT(PB-1962)


TRANSMIT RF/IF TRANSFORMER ALIGNMENT

- (1) Connect a dummy load to the antenna jack, and connect an audio signal generator to the microphone input. Tune up the transmitter at 14.2 MHz, and adjust the audio generator output for approximately 50 watts output into the dummy load, single-tone, SSB mode.
- (2) Peak T_{104} (RF UNIT) for maximum power output.
- (3) Peak T_{401} - T_{403} and T_{405} (IF UNIT) for maximum power output. Switch the RF processor on, and adjust the COMP LEVEL control for approximately 50 watts output. Peak T_{404} for maximum power output.




CLARIFIER ALIGNMENT

1. Tune in the marker generator signal on any band, and peak the preselector on the marker signal.
2. With the CLARIFIER control OFF, make sure that the CLARIFIER knob is exactly at the 12 o'clock position. Note the tone of the marker signal.
3. Switch the RX CLARIFIER to ON, and observe the tone of the marker signal. If it is different from when the clarifier was turned off, adjust VR₁₈₀₁ for an identical tone with the CLARIFIER knob exactly on the zero mark.



COUNTER UNIT

The carrier points for USB, LSB, and CW are preset as follows: USB = 91.011.0; LSB = 91.014.0; CW = 91.011.7. If, for some reason, it is desired to set these frequencies elsewhere, refer to the "Frequency Counter Preset Switch Position" drawing and chart. Adjustment of ± 200 Hz is possible as shown. The adjustment is carried out on the miniature switch shown in the drawing.



	LSB	USB	CW
+200Hz			
	91.014.2	91.011.2	91.011.9
+100Hz			
	91.014.1	91.011.1	91.011.8
±0			
	91.014.0	91.011.0	91.011.7
-100Hz			
	91.013.9	91.010.9	91.011.6
-200Hz			
	91.013.8	91.010.8	91.011.5


FINAL AMPLIFIER NEUTRALIZATION

Important Note: For this alignment, use a NON-METALLIC tuning wand.


1. Set the BAND switch to 10C, set the tuning dial to 29 MHz, and tune into a dummy load for approximately 70% full output power.
2. Set the METER switch to IC, and observe the dip in the cathode current. The dip should occur at the same point that maximum power output (measured on the dummy load wattmeter) occurs. If this is not the case, adjust TC₁, located inside the final amplifier cage, for the required coincidence of maximum power output and dip on the IC meter.

CAUTION: HIGH VOLTAGES ARE PRESENT ON THE UNDERSIDE OF THE CHASSIS AND INSIDE THE FINAL AMPLIFIER COMPARTMENT. USE GREAT CARE WHILE MAKING ADJUSTMENTS IN AREAS OF EXPOSED WIRING.

Note: The final amplifier enclosure must be in place to provide the required RF shielding during the neutralization procedure.



Final Amplifier Compartment



RECT A UNIT (PB-1967)

PARTS LIST

MAIN CHASSIS				C17	31830010	Ceramic	500WV	1pF
Symbol No.	Parts No.	Description		C10	31830050	"	"	5pF
		IC, TRANSISTOR		C18	31830470	"	"	47pF
Q2	22104960	2SA496		C11	31830201	"	"	200pF
Q1	22206160	2SB616		C19,21	31830271	"	"	270pF
Q3	25000116	μPC14308		C20	31830471	"	"	470pF
				C16	31844030	"	1KV	3pF
				C15	31844050	"	"	5pF
		DIODE		C14	31844101	"	"	100pF
D1	21090115	Ge	1N60	C3	31249461		1.5KWV	460pF
D2-5	21015550	Si	1S1555	C9	31249101	"	3KV	100pF
D6	21090011	"	10D1	C1	31249102	"	"	1000pF
				C29,34,35,41,	30820103	"	50WV	0.01μF
				C12,22-24,39,	30820473	"	"	0.047μF
		RESISTOR		40,56,58,60				
R22	40143220	Carbon film 1/4W TJ 22Ω		C27,28,36	30830472	"	500WV	0.0047μF
R14	41143560	"	" " " " 56Ω	C30,32,33,54,	30830103	"	"	0.01μF
R7,11	41143101	"	" " " " 100Ω	55, 61				
R18	41143821	"	" " " " 820Ω	C2,25,26	30240472	"	1.4KV	0.0047μF
R4,5	41143102	"	" " " " 1kΩ	C31,37,38,64	30240103	"	"	0.01μF
R6	41143152	"	" " " " 1.5kΩ	C42-51	32830102	Feed thru	500WV	0.001μF
R19	41143182	"	" " " " 1.8kΩ				(ECK-L2H102PE)	
R17	41143222	"	" " " " 2.2kΩ	C63	34220476	Electrolytic	16WV	47μF
R20	41143474	"	" " " " 470kΩ	C62	34220228	"	"	2200μF
R2	42124100	Carbon composition 1/2W GK						
			10Ω					
R9,10	42124560	"	" " " " 56Ω					
(with L5,L6)						VARIABLE CAPACITOR		
R3	42124101	"	" " " " 100Ω	VC1	39000083	YB-230		230pF
R1	42124222	"	" " " " 2.2kΩ	VC2	39000061	C134E125		
R21	42204229	Wire wound 1W 2.2Ω						
						TRIMMER CAPACITOR		
				TC1	39000072	TSN120C	10Px2	
		POTENTIOMETER						
VR1	49800140	VM11AB06A5M1112 10kΩ±						
VR2	49800123	DM10A039A 500kΩB/20kΩB				INDUCTOR		
VR3	49800124	DM10A039A 5kΩA/5kΩB		L1	55003396		#220534A	
VR4	49800141	VM10A592A 5kΩA		L2	55003398		#220611	
VR5,6	49800125	VM10A592A 5kΩB		L3	54000050		#220065	
VR7	49800126	DM10A039A 5kΩB/5kΩA		L4	54000040		#220064	
VR8	49800127	VM10A654A 1kΩB		L5,L6	55003216		#220308	
VR9,10	49800128	VM10A654A 5kΩB		(R9,R10)				
VR11	49800129	VM10AB08A 5kΩB		L7	53010003	250μH		
				L8	53020001	1mH	F'L-5H-102J	
		CAPACITOR						
	33834050	Dipped mica 500WV 5pF				TRANSFORMER		
C13	33834271	"	" " " 270pF	T1	55003398		#220544	
		(Z18D 271K5)		T2	55000460		#220011	
C8	33834331	"	" " " 330pF	T3	55000500		#220074	
		(DM-15-331K5)						
C7	33834621	"	" " 500WV 620pF					
		(DM19D621K5)						
C6	33834112	"	" " 500WV 1100pF			METER		
		(DM19 112K5)		M1	74000430	Y-45-02	#250042	
C5	33834302	"	" " 500WV 3000pF					
		(DM19 302K5)						
	33834681	"	" " 500WV 680pF					
		(LCQ21 681K5)				SPEAKER		
	33834122	"	" " 500WV 1200pF	SP1	76000019	SA-92Y	4Ω	3W
		(LCQ21 122K5)						

			P18 (with wire)	68030008	5047-03A #240129
			P11,14	67020007	SQ4052
		POWER TRANSFORMER	P15	67040002	SI5908
PT1	52000054	52-74 (#230028)	P16	67020009	SI-7502
		RELAY			FUSE
RL1	70000037	FRL-263 D012/04CS01	F1	73000004	5A (100V-117V)
RL2	70000002	MX2P		73000003	3A (200V-234V)
		RELAY SOCKET			FUSE HOLDER
RLS1	69000011	263H204	FH1	69030007	SN1001 #2
RLS2	69000003	PX08	FH2	69030001	F3265
		SWITCH			PILOT LAMP
S1	61000620	#250041	PL1	14000027	BF311-04071A
S2	61000630	#250044	PL2-5	14000037	BQ054-32732B
S3	62000031	ESR-E485R20			
S4,5	64000006	WD9223			
				91100001	Thru terminal FT-SM1
				91001339	" A339 (HV)
		COOLING FAN		92200007	Terminal block ML-3182 20P
FAN1	75000004	2SB10A		90010001	Terminal board 1L2PS
				90010002	" 1L3PS
				90020002	" 1L4PS
		RECEPTACLE			
J1,3	68030002	SG7814			
J2	68040003	FM144S			LED B BOARD
J4	67060006	D6-701B00	PB-1390	60413900	P.C.Board
J5 (with wire)	68090039	1625-09R-1 (#240128)	D9	21090140	GD4-203-SRD
J6	68020010	SI7501-1			
J7	68000011	M-BR-06B			
J8	68110001	SA602B00			
J9-14	68020001	STR-01			
J15	68020012	SG-8050			
J16	67090003	AC9-PF			
J17	68060021	QS-DB6-ML			
			RF UNIT		
			Symbol No.	Parts No.	Description
				019601AZ	RF unit with components
			PB-1960A	60419601	P.C. Board
		MULTI JACK			
MJ1	68100009	121S-10B-105A			
MJ2	68200002	220D-20B-205A			
MJ3	68140010	121S-14B-105A			FET & TRANSISTOR
			Q103,104	22800195	FET 2SK19GR
			Q105,106	23800401	" 3SK40M
			Q101	23800513	" 3SK51-03
			Q102	22890021	" J310
		PLUG	Q107	22390006	TR 2N4427
P1 (with wire)	68120011	5047-12A #240129			
P2 (")	68130003	5047-13A #240130			
P3 (")	68150009	5047-15A #240131			
P4 (")	68190001	5047-19A #240132			DIODE
P5 (")	68150010	5047-15A #240133	D104	21010070	Ge (GB) 1S1007
P6 (")	68080010	5047-08A #240134	D101-103	21015550	Si 1S1555
P7 (")	68050009	5047-05A #240135			
P8 (")	68080009	5047-08A			
P9 (")		5047-12A } #240137			
P10 (")		5047-16A			

		RESISTOR		NB-FIX UNIT		
				Symbol No.	Parts No.	Description
R119	40143479	Carbon film 1/4W VJ	4.7Ω			
R110	40143820	" " " "	82Ω		019612AZ	NB.FIX unit with components
R106-108,	40143101	" " " "	100Ω	PB-1961B	60419612	P.C. Board
116,120,121,						
130						
R111	40143221	" " " "	220Ω			
R113, 114,	40143331	" " " "	330Ω			TRANSISTOR
128,129				Q201-204	22303724	2SC372Y
R112	40143471	" " " "	470Ω	Q205,206	22315830	2SC1583
R118	40143821	" " " "	820Ω			
R105	40143102	" " " "	1kΩ			
R117	40143152	" " " "	1.5kΩ			
R102,109,122	40143272	" " " "	2.7kΩ			DIODE
R104,	40143562	" " " "	5.6kΩ	D201-204	21090115	Ge 1N60
R115	40143822	" " " "	8.2kΩ	D205-209	21015550	Si 1S1555
R124	40143223	" " " "	22kΩ			
R103	40143393	" " " "	39kΩ			
R123	40143563	" " " "	56kΩ			
R125	40143124	" " " "	120kΩ			RESISTOR
R101	42124225	Carbon composition 1/2W GK		R208,216,224,	40143101	Carbon film 1/4W VJ 100Ω
		2.2MΩ		230,238,239		
				R204	40143221	" " " " 220Ω
				R222,236	40143471	" " " " 470Ω
				R231-233,235	40143561	" " " " 560Ω
		CAPACITOR		R206,207,215,	40143102	" " " " 1kΩ
				221,234,237		
C125	33821030	Dipped mica 50WV 3pF		R210	40143472	" " " " 4.7kΩ
C107	33821040	" " " 4pF		R205,209,218	40143562	" " " " 5.6kΩ
C116	33821471	" " " 470pF		R202,203,212,	40143103	" " " " 10kΩ
C102,108	31829101	Ceramic 50WV SL 100pF		214,225,226		
C103-106,	30821103	" 50WV 0.01μF		R201,220,223	40143153	" " " " 15kΩ
110-112,				R211,213,219	40143223	" " " " 22kΩ
114,115,117,				R217	40143683	" " " " 68kΩ
119-124						
C101,118	30820473	" " 0.047μF				
C113	34220106	Electrolytic 16WV TT 10μF				
						CAPACITOR
				C216-218	33821331	Dipped mica 50WV 330pF
		TRIMMER CAPACITOR		C234,236	33821471	" " " 470pF
TC101	39000006	ECV-1ZW 10x40 10pF		C235	33821821	" " " 820pF
				C208,209	31820150	Ceramic 50WV NPO 15pF
				C206	31829200	" " SL 20pF
				C204	31829101	" " SL 100pF
		INDUCTOR		C201	31829331	" " " 330pF
L101,102	53020027	FL-5H 271K 270μH		C202,203,205,	30820103	" " 0.01μF
				211,212,221,		
				225-227,		
				229-233		
		TRANSFORMER		C207,210,213,	30820473	" " 0.047μF
T101,103,105	55003174	#220209		215,219,220,		
T102,104	55003175	#220221		223,224,228,		
				237		
				C214	34820105	Electrolytic 50WV 1μF
		JACK				
J101-103	68020021	SQ3081				
						TRIMMER CAPACITOR
				TC201,202	39000005	ECV-1ZW 50x32 50pF

		INDUCTOR		C312-314, 316-318, 320-322, 324-326, 328, 329 331-343	30820103	Ceramic 50WV	0.01μF
L207,208	53020014	FL-4H 1R8K	1.8μH				
L204-206	53020023	FL-5H 101K	100μH				
L201-203	53020001	FL-5H 102K	1mH				
				C303,307,327	36825102	Mylar "	0.001μF
		TRANSFORMER					
T201,202	54141700	R12-4170					
		CRYSTAL SOCKET		L317	53020035	INDUCTOR	
XS201	69010007	S-14 2P		L301-314	53020027	FL-4H 1R0M	1μH
				L315,316,318, 319	53020001	FL-5H 271K	270μH
						FL-5H 102K	1mH
		MINI CONNECTOR					
J201	67080006	5048-08A					
J202	67120010	5048-12A				TRANSFORMER	
				T301,302	55003399	#220500	
				T303,304	55003400	#220501	
				T305,306	55003401	#220502	
				T307,308	55003403	#220504	
				T309,310	55003405	#220505	
				T311,312	55003406	#220506	
				T313,314	55003407	#220507	
				T315	55003409	#220510	
PREMIX UNIT							
Symbol No.	Parts No.	Description					
	019621AZ	PREMIX unit with components					
PB-1962A	60419621	P.C. Board					
						JACK	
		IC. FET. TRANSISTOR		J301	68020021	SQ3081	
Q303	25000104	IC	SN76514N	P301	67020007	SQ4052	
Q301	22800195	FET	2SK19GR				
Q302	22303730	TR	2SC373				
		DIODE		IF UNIT			
D301-314	21015550	Si	1S1555	Symbol No.	Parts No.	Description	
					019632AZ	IF unit with components	
					PB-1963B	P.C. Board	
		RESISTOR					
R312	40143101	Carbon film 1/4W VJ	100Ω			IC. FET. TRANSISTOR	
R316,318	40143121	" " " "	120Ω	Q403	25000105	IC	TA7060P
R317	40143151	" " " "	150Ω	Q406	22800196	FET	2SK19BL
R311,315	40143221	" " " "	220Ω	Q402,413,414, 419,425	22800195	"	2SK19GR
R301-309	40143222	" " " "	2.2kΩ				
R310,313,314	40143103	" " " "	10kΩ	Q401,405,412, 415,416	23800513	"	2SK51-03
				Q408	228900021	"	J310
				Q407,420	22105641	TR	2SA564A
				Q404,409,410, 417, 418, 422-424	22303724	"	2SC372Y
		CAPACITOR					
C323	33824390	Dipped mica	50WV 39pF	Q421	22305351	"	2SC535A
C319	33824271	" "	" 270pF	Q411	22390001	"	MPSA13
C311,315	33824681	" "	" 680pF				
C330	31820151	Ceramic	50WV CH150pF			DIODE	
C301, 302	30820103	" "	0.01μF	D416,417	21090150	Ge	1N60
304-306, 308-310,				D405-408, 414, 421	21010070	" (GB)	1S1007

D401-404,	21015550	Si	1S1555	R407,415,438,	40143153	" " " VJ	15kΩ
409-413,				476,498,499			
419					40143223	" " " "	22kΩ
D418	21022090	Varactor	1S2209	R414	40143273	Carbon film 1/4W TJ	27kΩ
D422	21090137	"	FC63	R461,472,478,	40143473	" " " "	47kΩ
D420, 423	21090034	Zener	WZ090	0500			
				R405,432,441,	40143104	" " " "	100kΩ
				465,466			
		CRYSTAL		R493	49143154	" " " "	150kΩ
X401	71800111	HC-18/U	19.7475MHz	R448,452,487,	40143184	" " " "	180kΩ
				0503,0505			
					40143224	" " " "	220kΩ
				R435, 490	40143105	" " " "	1MΩ
		CRYSTAL FILTER			40143225	" " " "	2.2MΩ
XF401	71000023		XF8.9HS	R0519	42144566	" Composition GK	5.6MΩ
XF402	71000021		XF8.9HC				
(OPTION)							
XF403	71000040		XF8.9HP			POTENTIOMETER	
XF404	71200017		8.9M20A	VR401,402	49905102	SR-19R	1kΩB
XF405	71000024		XF10GS	VR403,404	49905103	"	10kΩB
				VR405	49905473	"	47kΩB
		RESISTOR					
R0517,0518,0520	40143220	Carbon film 1/4W VJ	22Ω				
R410, 411	41143101	" " " TJ	100Ω			CAPACITOR	
R402,408,419,	40143101	" " " VJ	100Ω	C477	33824221	Dipped mica	50WV 220pF
422,423,437,				C445,472	31820100	Ceramic	50WV CH10pF
439,444,446,				C488,492	31827330	"	" UJ 33pF
463,464,469,				C489	31827390	"	" UJ 39pF
475,482,483,				C404,421,432	31820470	"	" CH47pF
497,0514				C487	31827101	"	" UJ 100pF
R425,447,451,	40143221	" " " "	220Ω	C459,464,475	31820101	"	" CH100pF
486, 0507,				C401,405,406,	30820103	"	" 0.01μF
0508				411,413,415,			
R0502	40143331	" " " "	330Ω	417,419,420,			
	40143391	" " " "	390Ω	423,424,428,			
R443	40143471	" " " "	470Ω	430,431,433,			
R430,474,480	40143561	" " " "	560Ω	435,440,442,			
R467,468	40143681	" " " "	680Ω	443,446,448,			
R0515	40143821	" " " "	820Ω	451-455,			
R406,416,428,	40143102	" " " "	1kΩ	460,465,482,			
437,440,442,				484-486,			
449,453,457,				490,491,493,			
459,462,488,				494,497			
494,0504,				C402,403,407,	30820473	"	" 0.047μF
0506				408,410,412,			
R429,495,	40143152	" " " "	1.5kΩ	414,416,418,			
R0516	41143182	" " " TJ	1.8kΩ	422,425-427,			
R454,455,458,	40143222	" " " VJ	2.2kΩ	429,436-438,			
0510				441,444,447,			
R460	40143272	" " " "	2.7kΩ	457,458,462,			
R401,409,412,	40143332	" " " "	3.3kΩ	463,468-471,			
413,417,431,				473,474,495,			
456,496,0511				498			
R426,427	40143472	" " " "	4.7kΩ	C449	30820104	"	" 0.1μF
R403,445,481,	40143562	" " " "	5.6kΩ	C461,467	36825103	Mylar	50WV 0.01μF
489				C478	36825223	"	" 0.022μF
R434, 450	40143682	" " " "	6.8kΩ	C409,439,456,	36825473	"	" 0.047μF
R404,420,421,	40143103	" " " "	10kΩ	466,480,481,			
424,436,470,				483			
471,477,484,				C434	36526224	Tantalum	35WV 0.22μF
485,491,492,				C479	36526225	"	" 2.2μF
0501, 0509,				C450,476,496	34220106	Electrolytic	16WV 10μF
0512					34220336	"	" 33μF
R433	41143103	" " " TJ	10kΩ				

		INDUCTOR				
L401–408, 410	53020023	FL-5H 101K	100μH			CRYSTAL
L411, 412	53020027	FL-5H 271K	270μH	X501	71600032	HC-6/W 3200kHz #210026
L409	55003178	5.2μH	#220145	X502	71800085	HC-18/U 8986kHz #210042-1
				X503	71800086	" 8989kHz #210042-2
				X504	71800087	" 8988.3kHz #210042-3
		TRANSFORMER				
T410	54140740	R12-4074				
T402,403,404, 407,409,413, 414	54141700	R12-4170				
						RESISTOR
T401,406,408, 415	54141710	R12-4171		R511	40143479	Carbon film 1/4W VJ 4.7Ω
T405	55003177	#220221		R509,539,557	40143101	" " " " 100Ω
T411	55003410	#220460		R533,546	40143151	" " " " 150Ω
T412	55003174	#220209		R503,513,524, 525	40143221	" " " " 220Ω
				R512,522,538	40143471	" " " " 470Ω
				R504,514,520, 523,548,561	40143102	" " " " 1kΩ
		MINI CONNECTOR		R515	40143222	" " " " 2.2kΩ
J401	67120010	5048-12A		R534,535,565	40143272	" " " " 2.7kΩ
J402	67130001	5048-13A		R510,562,569,	40143332	" " " " 3.3kΩ
J403	67150010	5048-15A		571,578–580		
					40143392	3.9kΩ
				R501,506,507, 531,536,537,	40143472	" " " " 4.7kΩ
TP401–412	91100008	Wrapping terminal		542,544,545, 549,550,563, 566,575,576, 581		
				R521,527,532, 541,568,570	40143682	" " " " 6.8kΩ
				R519,529,555, 556,558,572	40143103	" " " " 10kΩ
AF UNIT				R517,551	40143153	" " " " 15kΩ
Symbol No.	Parts No.	Description		R508,518,528, 540,554,573	40143223	" " " " 22kΩ
	019641AZ	AF unit with components		R559	40143393	" " " " 39kΩ
PB-1964A	60419641	P.C. Board		R567	40143473	" " " " 47kΩ
				R516	40143563	" " " " 56kΩ
		IC. FET. TRANSISTOR		R547,574	40143104	" " " " 100kΩ
Q503	25000125	IC	MC3403P	R560	40143154	" " " " 150kΩ
Q506	25000177	"	MC14024B	R553	40143224	" " " " 220kΩ
Q504	25000151	"	SN74LS123N	R526	40143274	" " " " 270kΩ
Q502	25000134	"	TA7063P	R552,564,577	40143474	" " " " 470kΩ
Q501	25000210		μPC2002H	R582	40143824	" " " " 820kΩ
Q505	25000172	"	78L05	R505	42124229	" composition 1/2W GK 2.2Ω
Q514	22800195	FET	2SK19GR	R502	44104010	Wire wound 1W 1Ω
Q515	22105640	TR	2SA564			
Q511	22303730	"	2SC373			
Q507,508	22310005	"	2SC1000GR			
Q512	22313830	"	2SC1383			
Q509,510,513, 516	22318154	"	2SC1815Y			
						POTENTIOMETER
				VR501	49918101	CR-19R 100ΩB
		DIODE				
D506,510,511	21090115	Ge	1N60			
D502–505	21010070	Ge (GB)	1S1007			
D507–509, 512–517, 520,519,521	21015550	Si	1S1555			CAPACITOR
D501,518	21090011	"	10D1	C512	33824271	Dipped mica 50WV 270pF
				C513	33824510	" " " 510pF
				C511	31820030	Ceramic 50WV CH3pF
				C522	31820100	" " 10pF
				C514	31820270	" " 27pF

C546-548	31820390	Ceramic	50WV	39pF	PREMIX LOCAL UNIT		
C510,532,534, 555,566	31820101	"	"	100pF	Symbol No.	Parts No.	Description
C533	31820151	"	"	150pF		019650AZ	PREMIX LOCAL unit with
C558,559	31820241	"	"	240pF	PB-1965	60419650	components P.C. Board
C504,519-521, 523,531,535, 542-545, 562,570	30820103	"	"	0.01 μ F			
C509,537	30820473	"	"	0.047 μ F	Q601-610	22303724	TRANSISTOR 2SC372Y
C516	36825102	Mylar	"	0.001 μ F			
C526	36825472	"	"	0.0047 μ F			
C518,529,530, 572	36825103	"	"	0.01 μ F			DIODE
C525,539-541	36825223	"	"	0.022 μ F	D601-610	21015550	Si 1S1555
C556,567,569, 573	36825473	"	"	0.047 μ F			
C503,528	36825104	"	"	0.1 μ F			
C507,517,527, 550,551,560, 568,571	34820105	Electrolytic	"	1 μ F			RESISTOR
C557	34320225	"	25WV	2.2 μ F	R604,608,612, 616,620,624, 628,632,636, 640	40143101	Carbon film 1/2W VJ 100 Ω
C561	34320335	"	"	3.3 μ F			
C536	34320475	"	"	4.7 μ F	R642	40143181	" " " " 180 Ω
C505,515,538, 552,554,564, 565	34220106	"	16WV	10 μ F	R603,607,611, 615,619,623, 627,631,635, 639	40143102	" " " " 1k Ω
C524,553,563	34220226	"	"	22 μ F			
C508	34220476	"	"	47 μ F	R641,643	40143122	" " " " 1.2k Ω
C501	34220107	"	"	100 μ F	R602,606,610, 614,618,638	40143183	" " " " 18k Ω
C506	34220227	"	"	220 μ F			
C502	34220477	"	"	470 μ F	R622,626,630, 634	40143333	" " " " 33k Ω
					R601,605,609, 613,617,621, 625,629,633, 637	40143563	" " " " 56k Ω
		TRIMMER CAPACITOR					
TC501-505	39000002	ECV-1ZW	20x32	20pF			
		INDUCTOR					
L502	53020019	FL-5H 220		22 μ H			
L501	53020027	FL-5H 271		270 μ H			CAPACITOR
L503-506	53020001	FL-5H 102		1mH	C624,628,632, 636	31820470	Ceramic 50WV CH47pF
					C620	31820680	" " " " 68pF
					C616	31820101	" " " " 100pF
		TRANSFORMER			C612	31820181	" " " " 180pF
T501	55003174	#220209			C640	31820241	" " " " 240pF
					C608	31820271	" " " " 270pF
					C604	31820331	" " " " 330pF
					C601-603, 605-607, 609-611, 613-615, 617-619, 621-623, 625-627, 629-631, 633-635, 637-639,641	30820103	" " " " 0.01 μ F
		RELAY					
RL501	70000031	FBR211A D012M					
		MINI CONNECTOR					
J501	67190001	5048-19A					
J502	67150010	5048-15A					
J503	67080006	5048-08A					
J504	67050005	5048-05A					
J505	67030005	5048-03A					
	80042800	HEAT SINK					

		CRYSTAL			DIODE
X601	71800113	HC-18/U 15.9875MHz #210147	D801	21022360	Varactor 1S2236
X602	71800114	" 17.9875 " #210148			
X603	71800115	" 21.4875 " #210149			
X604	71800116	" 28.4875 " #210150			
X605	71800117	" 35.4875 " #210151			RESISTOR
X606	71800118	" 42.4875 " #210152	R809, 811	40143101	Carbon film 1/4W VJ 100Ω
X607	71800119	" 42.9875 " #210153	R807	40143221	" " " " 220Ω
X608	71800120	" 43.4875 " #210154	R805, 808	40143222	" " " " 2.2kΩ
X609	71800121	" 43.9875 " #210155	R802	40143332	" " " " 3.3kΩ
X610	71800122	" 19.4875 " #210156	R801	40143103	" " " " 10kΩ
			R803	40143183	" " " " 18kΩ
			R804	40143223	" " " " 22kΩ
			R806, 810	40143104	" " " " 100kΩ
		TRANSFORMER			
T601-610	55003217	#220017			
					CAPACITOR
			C807	31820080	Ceramic disc 50WV 8pF CH
			C801	31827080	" " " 8pF UJ
			C803	31827120	" " " 12pF UJ
			C804	31820180	" " " 18pF CH
			C814,	31820330	" " " 33pF CH
			C805, 808, 818	31820390	" " " 39pF CH
			C809, 810, 812,	30820103	" " " 0.01μF
			815, 819, 820,		
			824, 826		
		DIODE	C811	33824181	Dipped mica " 180pF
D701	21090011	Si 10D1	C813	33824431	" " " 430pF
			C821, 823	33824471	" " " 470pF
			C802, 822	33824102	" " " 1000pF
			C825	36226334	Tantalum 10WV 0.33μF
		RELAY			
RL701	70000031	FBR211A D012M			
					VARIABLE CAPACITOR
			VC801	39000027	C521
		SWITCH			
S701	65000047	6B0003CC2060			
					TRIMMER CAPACITOR
			TC801	39000070	TSN-100D15 15pF
		MINI CONNECTOR	TC802	39000005	ECV-1ZW 50x32 50pF
J701	67160003	5048-16A			
					INDUCTOR
			L801	55003184	#220268
			L804,805	53020014	Micro inductor FL-4H 1.8μH
			L803,806	53010003	" " 250μH
			L802	53030001	" " S4 102K 1mH
		VFO UNIT (3420)			
		VFO assembly 3420			
	014402BZ	PCB with components			
PB-1440B-3420	60414402	P.C. Board			
					RECEPTACLE
			J801	68040001	SI-6303-1
		FET & TRANSISTOR			
Q802	22800195	FET 2SK19GR			
Q801, 803	22303724	Transistor 2SC372Y			TERMINAL
				90000000	Lighthouse type
				91100008	Wrapping terminal C


RECT. A UNIT					DIODE	
Symbol No.	Parts No.	Description	D1004, 1005, 1008-1011	21015550	Si	1S1555
	019670AZ	RECT. A unit with components				
PB-1967	60419670	P.C. Board	D1001-1003	21090019	"	10D10
			D1006, 1007	21090011	"	10D1
		IC. TRANSISTOR				
Q901	25000209	IC μ PC78L12				
Q903	22104950	TR 2SA495	R1021	40143102	RESISTOR	
			R1011,1016, 1020	40143472	Carbon film 1/4W VJ 1k Ω	
					" " " " 4.7k Ω	
			R1013,1015	40143103	" " " " 10k Ω	
			R1014	40143123	" " " " 12k Ω	
D907	21090011	Si 10D1	R1017-1019	40143223	" " " " 22k Ω	
D901-904	21090019	" 10D10	R1012	40143563	" " " " 56k Ω	
D905,906	21090022	" V06B	R1001-1004	42143474	" composition 1/2W GK 470k Ω	
D908	21090154	Zener WZ061	R1010	43104562	Metallic film 1W 5.6k Ω	
			R1005,1006	43204471	" " 2W 470 Ω	
			R1008	43204222	" " " " 2.2k Ω	
			R1007	43204332	" " " " 3.3k Ω	
			R1009	43204473	" " " " 47k Ω	
		RESISTOR				
R908	40143560	Carbon film 1/4W VJ 56 Ω				
R905	42124100	" composition 1/2W GK 10 Ω				
R901-904	42124474	" " " " 470k Ω				
R907	43204049	Metallic film 2W 0.4 Ω				
					POTENTIOMETER	
			VR1001	49910103	V18K3-2	10k Ω B
		CAPACITOR				
C901-905	30820103	Ceramic 50WV 0.01 μ F			CAPACITOR	
C908-911	34320106	Electrolytic 25WV 10 μ F	C1017	30820473	Ceramic 50WV	0.047 μ F
C907	34320107	" " 100 μ F	C1016	30830222	" 500WV	0.0022 μ F
C906	34320338	" " 3300 μ F	C1005,1006, 1013-1015, 1018	30830472	" "	0.0047 μ F
			C1010	30830103	" "	0.01 μ F
			C1009	34330106	Electrolytic 250WV	10 μ F
			C1011	34330226	" "	22 μ F
		RELAY	C1001-1004, 1012	34330476	" "	47 μ F
RL901	70000036	FRL-264 D012/04CS-01				
	91100008	Wrapping terminal	C1007,1008	34350226	" 350WV	22 μ F
	91100005	Test point D				
				91100008	Wrapping terminal	
RECT. B UNIT						
Symbol No.	Parts No.	Description	CAPACITOR UNIT			
	019680AZ	RECT. B unit with components	Symbol No.	Parts No.	Description	
PB-1968A	60419681	P.C. Board		019691AZ	CAPACITOR unit with components	
			PB-1969A	60419691	P.C. Board	
		TRANSISTOR				
Q1003	22106390	2SA639				
Q1001	22107330	2SA733				
Q1002	22303724	2SC372Y				
			R1101,1102	42124474	RESISTOR	
					Carbon composition 1/2W GK 470k Ω	

[illegible]

		SWITCH			VACUUM TUBE
S1501	65000034	1B0001AC2060	V1701,1702	10000026	6146B
					VACUUM TUBE SOCKET
			VS1701,1702	68080006	SB-3606
DRIVER BOARD					
Symbol No.	Parts No.	Description			
	017140AZ	Driver board with components			
		(without vacuum tube)			RESISTOR
PB-1714A	60417141	P.C. Board	R1701,1702	42124560	Carbon composition 1/2W GK
			(L1702,1703)		56Ω
			R1703,1704,	42124100	" " " " 100Ω
			1705		
		VACUUM TUBE	R1706	44201010	Meter shunt 2W 1Ω
V1601	10000020	12BY7A			
		VACUUM TUBE SOCKET			CAPACITOR
VS1601	68090006	SB-9403	C1703,1704,	30830103	Ceramic disc 500WV 0.01μF
			1710		
			C1705-1709,	30820473	" " 50WV 0.047μF
			1711,1712		
		RESISTOR		30830102	" " 500WV 1000pF
R1605	42124470	Carbon composition 1/2W GK	C1701	33147102	Moulded mica 1kWV 1000pF
		47Ω	C1702	33831050	Dipped mica 500WV 5pF
R1602,1604	42124560	" " " " 56Ω			
R1603	42124101	" " " " 100Ω			
R1601	42124473	Carbon composition 1/2W GK			
		47kΩ			
					INDUCTOR
			L1701	53020013	Micro inductor 150μH
			L1704	53020015	Micro inductor 560μH
			L1702,1703	53003220	RF choke #220307
			(R1701,1702)		
		CAPACITOR			
C1601,1602	30830103	Ceramic disc 500WV 0.01μF			
C1603,1604,	30820473	" " 50WV 0.047μF			
1606				91100008	Wrapping terminal C
C1605	33834102	Dipped mica 500WV 1000pF			
			CLARIFIER CONTROL UNIT		
		INDUCTOR	Symbol No.	Parts No.	Description
L1601	53020013	Micro inductor FL5H 150μH		019731AZ	CLAR CONT. unit with
L1602(R1602)	55003219	#220029			components
			PB-1973A	60419731	P.C. Board
	91100008	Wrapping terminal B			
					DIODE
			D1801	21090011	Si 10D1
			D1802	20900140	LED GD4-203SRD
FINAL BOARD					
Symbol No.	Parts No.	Description			RESISTOR
	017151AZ	Final board with components	R1803	40143102	Carbon film 1/4W VJ 1kΩ
		(without vacuum tube)	R1804,1805	40143152	" " " " 1.5kΩ
PB-1715A	60417151	P.C. Board	R1802	40143332	" " " " 3.3kΩ
			R1801	40143472	" " " " 4.7kΩ

				S2001-2005	64000109	SWITCH		SLE62351
				S2006	64000108			SLE64251
		POTENTIOMETER						
VR1801	49915471	V10K8-1-2	470ΩB					
				COUNTER UNIT				
				Symbol No.	Parts No.	Description		
		CAPACITOR			019800AZ	COUNTER unit assembly		
C1801-1803	30820473	Ceramic	50WV 0.047μF	PB-1978	-	(Display board)		
				PB-1979	-	(Count, decode board)		
				PB-1980	-	(Main board)		
		RELAY						
RL1801	70000031	FBR211A	D012M					
				DISPLAY board				
				PB-1978	60419780	P.C. Board		
		SWITCH						
SW1801	65000046	2B0005FC206						
						DISPLAY LED		
				DS2101-2106	21090153	HP5082-7623		
LED BOARD								
Symbol No.	Parts No.	Description				SOCKET		
	019741AZ	LED board with components		QS2101-2106	68140005	314AG-37D		
PB-1974A	60419741	P.C. Board						
		LED		COUNT. DECODE board				
D1901-1906	20900140	GD4-203SRD		PB-1979	60419790			
		RESISTOR				IC. TRANSISTOR		
R1901,1902	41143102	Carbon film 1/4W TJ	1kΩ	Q2208-2213	25000085	IC	MSM561RS	
				Q2202-2207	25000204	"	SN74LS196N	
				Q2201	22104964	TR	2SA496Y	
LEVER SWITCH BOARD						RESISTOR		
Symbol No.	Parts No.	Description		R 2204-2245	40143101	Carbon film 1/4WS VJ	100Ω	
	019751AZ	LEVER SW board with		R2203	40143181	" " " "	180Ω	
		components		R2202	40143271	" " " "	270Ω	
PB-1975A	60419751	P.C. Board		R2201	40143471	" " " "	470Ω	
						(ALL RD¼F(R2) TYPE)		
		RESISTOR						
R2006	41143560	Carbon film 1/4W TJ	56Ω					
R2005	41143101	" " " "	100Ω					
R2001	41143121	" " " "	120Ω			CAPACITOR		
R2002	40143391	" " " " VJ	390Ω	C2201	30820103	Ceramic 50WV	0.01μF	
R2008	41143562	" " " " TJ	5.6kΩ			(2222-662-02-103)		
R2007	40143103	" " " " VJ	10kΩ	C2202-2204	36326685	Tantalum 6.3WV	6.8μF	
R2004	40143683	" " " " "	68kΩ			(CS99E0J6R8M)		

[illegible]



IMPORTANT

THIS IS YOUR WARRANTY REGISTRATION CARD

RETAIN THIS HALF

Model FT 101ZD Serial 9H080

WARRANTY REGISTRATION CARD

THIS CARD MUST BE MAILED TO
THE DEALER WITHIN 10 DAYS
FROM THE DATE OF PURCHASE.

DATE OF PURCHASE _____

OWNER'S NAME _____ CALL _____

ADDRESS _____

DEALER'S NAME _____

SERIAL NO. 9H080

MODEL NO. FT 101ZD

WARRANTY POLICY

We warrant this equipment against defects in material or workmanship, with the exception of tubes and semiconductors, for a period of one year from the date of original purchase. This warranty is limited to repairing or replacing only the defective parts, and is not valid if the equipment has been tampered with, misused or damaged. If service or repair is required within the warranty period, repair will be made free of charge by the dealer through whom the equipment was purchased. If the owner requires any service or repair to any dealer through whom the equipment was not purchased, the repairing cost must be paid by the owner.

This warranty is valid if the enclosed card is properly filled in and mailed to the dealer through whom the equipment was purchased within ten days from the date of purchase, and is limited to the terms and conditions contained herein.

The manufacturer retains the right to make changes or modifications without any notice or obligation to the owner of this equipment.

YAESU MUSEN CO., LTD.

PLACE

STAMP

HERE

Meus mais sinceros agradecimentos a PY3UA Barros pelo empréstimo do manual para digitalização
Digitalizado por Alexandre Souza, PU2SEX em Novembro de 2021
DISTRIBUICAO GRATUITA

